



ENGLISH

Anybus® Wireless Bolt 5G™

## USER MANUAL

SCM-1202-232

Version 1.0

Publication date 2024-07-09



## Important User Information

### **Disclaimer**

The information in this document is for informational purposes only. Please inform HMS Networks of any inaccuracies or omissions found in this document. HMS Networks disclaims any responsibility or liability for any errors that may appear in this document.

HMS Networks reserves the right to modify its products in line with its policy of continuous product development. The information in this document shall therefore not be construed as a commitment on the part of HMS Networks and is subject to change without notice. HMS Networks makes no commitment to update or keep current the information in this document.

The data, examples and illustrations found in this document are included for illustrative purposes and are only intended to help improve understanding of the functionality and handling of the product. In view of the wide range of possible applications of the product, and because of the many variables and requirements associated with any particular implementation, HMS Networks cannot assume responsibility or liability for actual use based on the data, examples or illustrations included in this document nor for any damages incurred during installation of the product. Those responsible for the use of the product must acquire sufficient knowledge in order to ensure that the product is used correctly in their specific application and that the application meets all performance and safety requirements including any applicable laws, regulations, codes and standards. Further, HMS Networks will under no circumstances assume liability or responsibility for any problems that may arise as a result from the use of undocumented features or functional side effects found outside the documented scope of the product. The effects caused by any direct or indirect use of such aspects of the product are undefined and may include e.g. compatibility issues and stability issues.

Copyright © 2024 HMS Networks

### **Contact Information**

Postal address:  
Box 4126  
300 04 Halmstad, Sweden

E-Mail: [info@hms.se](mailto:info@hms.se)

# Table of Contents

<b>1. Preface</b>	<b>1</b>
1.1. About This Document	1
1.2. Document Conventions	1
1.3. Trademarks	2
<b>2. Safety</b>	<b>3</b>
2.1. General Safety	3
2.2. Intended Use	3
<b>3. Preparation</b>	<b>4</b>
3.1. Support and Resources	4
3.2. Network Environment	4
3.3. SIM Card	4
3.4. Required Distance Between Devices	4
3.5. Surface Heat Considerations	4
3.6. Firewall and Routing	5
<b>4. Installation</b>	<b>6</b>
4.1. Install SIM Card	6
4.2. Installation Drawing	7
4.3. Surface Mounting	8
4.4. To Lock the Bolt 5G Position	11
4.5. Signal and Power Connector Cabling	14
4.5.1. Signal and Power Connector Pinout	14
4.5.2. DC Power Interface	14
4.5.3. Connector Type	14
4.6. Connect to DC Power	15
4.7. Connect to Power Over Ethernet (PoE)	17
4.8. Connect to Ethernet	19
4.9. Frequency Bands and Power Level	20
<b>5. Configuration</b>	<b>22</b>
5.1. Connect to Configure	22
5.1.1. Connect to PC and DC Power	22
5.1.2. Connect to PC and Power over Ethernet (PoE)	22
5.2. Access the Built-In Web Interface	23
5.2.1. Required IP Address Settings	23
5.2.2. Login to the Built-In Web Interface	24
5.3. Bolt 5G Built-In Web Interface Overview	26
5.4. Factory Default Settings	27
5.5. Setup Virtual Tunnel	28
5.6. Cellular Settings	31
5.6.1. Network Settings	31
5.6.2. Operator Selection	32
5.6.3. SIM Settings	33
5.6.4. APN Settings	34
5.7. Tunnel Settings	36
5.8. Ethernet Settings	38
5.9. NAT Settings	39
<b>6. Verify Operation</b>	<b>40</b>
6.1. Bolt 5G Status Monitor	40

6.2. Bolt 5G LED Status Indication .....	42
6.3. Ethernet RJ45 LED Status Indication .....	43
<b>7. Maintenance .....</b>	<b>44</b>
7.1. Time & Date Settings .....	44
7.1.1. Set Time .....	44
7.1.2. Network Time Protocol (NTP) Synchronization .....	45
7.1.3. Use Timezone Settings .....	46
7.2. Configuration File Handling .....	47
7.2.1. Export Configuration .....	47
7.2.2. Import Configuration .....	48
7.3. Revert Configuration .....	49
7.4. Firmware Management .....	50
7.4.1. View the Firmware Version .....	50
7.4.2. Firmware and Configuration Compatibility .....	50
7.4.3. Firmware File Validation .....	50
7.4.4. Update Firmware .....	51
7.5. Web Server Certificate Settings .....	52
7.6. Remote Access to Bolt 5G Built-In Web GUI .....	53
7.7. Change the Bolt 5G Password .....	54
<b>8. Troubleshooting .....</b>	<b>55</b>
8.1. Find the Bolt 5G IP Address .....	55
8.2. Diagnostics .....	56
8.2.1. Event Log .....	56
8.2.2. Commands .....	57
8.2.3. History Monitor .....	61
8.3. Reboot Using the Built-In Web Interface .....	62
8.4. Reboot Using the Reset Button .....	64
8.5. Reset Using the Built-In Web Interface .....	66
8.6. Reset Using the Reset Button .....	68
<b>9. Technical Data .....</b>	<b>69</b>
9.1. Technical Specifications .....	69

# 1. Preface

## 1.1. About This Document

This document describes how to install and configure Anybus® Wireless Bolt 5G™.

For additional documentation and software downloads, FAQs, troubleshooting guides and technical support, please visit [www.hms-networks.com](http://www.hms-networks.com).

## 1.2. Document Conventions

### Lists

Numbered lists indicate tasks that should be carried out in sequence:

1. First do this
2. Then do this

Bulleted lists are used for:

- Tasks that can be carried out in any order
- Itemized information

### User Interaction Elements

User interaction elements (buttons etc.) are indicated with bold text.

### Program Code and Scripts

```
Program code and script examples
```

### Cross-References and Links

Cross-reference within this document: [Document Conventions \(page 1\)](#)

External link (URL): [www.hms-networks.com](http://www.hms-networks.com)

### Safety Symbols



#### DANGER

Instructions that must be followed to avoid an imminently hazardous situation which, if not avoided, will result in death or serious injury.



#### WARNING

Instructions that must be followed to avoid a potential hazardous situation that, if not avoided, could result in death or serious injury.



#### CAUTION

Instruction that must be followed to avoid a potential hazardous situation that, if not avoided, could result in minor or moderate injury.



#### IMPORTANT

Instruction that must be followed to avoid a risk of reduced functionality and/or damage to the equipment, or to avoid a network security risk.

## Information Symbols



### NOTE

Additional information which may facilitate installation and/or operation.



### TIP

Helpful advice and suggestions.

## 1.3. Trademarks

Anybus® Wireless Bolt 5G™ is a trademarks of HMS Networks AB.

All other trademarks are the property of their respective holders.

## 2. Safety

### 2.1. General Safety

**CAUTION**

Ensure that the power supply is turned off before connecting it to the equipment.

**CAUTION**

To ensure proper functioning and electrical safety, connect the Bolt 5G Functional Earth (FE) connection to earth.

**CAUTION**

The supply circuit must be limited to PS2 or fulfill the requirements in IEC 62368-1:2023 standard Annex Q, equivalent to Limited Power Source (LPS).

The supply circuit transient voltages must not exceed 1500 V.

**IMPORTANT**

When powering the Bolt 5G, do not use PoE and DC power at the same time. Ensure to use only one source of power.

**IMPORTANT**

To prevent wires from overheating, use a power supply wire rated to carry the rated current of the Bolt 5G.

### 2.2. Intended Use

The intended use of this equipment is as a communication interface and router.

The equipment receives and transmits data over wired and cellular standard networks.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

## 3. Preparation

### 3.1. Support and Resources

For additional documentation, software downloads and technical support, please visit [www.hms-networks.com](http://www.hms-networks.com).

### 3.2. Network Environment

Ensure that you have all the necessary information about the capabilities and restrictions of your local network environment before installation.

### 3.3. SIM Card



#### NOTE

The supported SIM card type is Nano SIM (4FF).

### SIM Card Data Plan

Use a SIM card with a data plan suitable for the application and network.

### 3.4. Required Distance Between Devices

At least 20 cm separation distance between the device and the user's body must be maintained at all times.

### 3.5. Surface Heat Considerations

Mount the Bolt 5G on a surface with good thermal conductance to the surrounding air.

For optimal thermal performance, it is recommended that the heat transfer capacity of the surface corresponds to a square aluminum plate with a minimum side dimension of 300 mm and a thickness of 3 mm.




Figure 1. Mounting surface heat dissipation area

## 3.6. Firewall and Routing

There are routing options set for the system.

By default, the firewall allows routing of:

- Outgoing traffic for TCP, UDP and ICMP (for IPv4 only).
- Incoming traffic for already established connections only.

For other possible configurations, see [NAT/Passthrough Settings](#).

## 4. Installation

### 4.1. Install SIM Card

**NOTE**

The supported SIM card type is Nano SIM (4FF).




Figure 2. Insert SIM card

To connect Bolt 5G to a cellular data network, install a cellular SIM card:


1. Remove the SIM card holder plug.
2. Insert a SIM card into the push-push SIM card holder.

**NOTE**

Ensure that the SIM card contact surface is facing towards the Ethernet port.

3. Attach the SIM card holder plug.

### 4.2. Installation Drawing



All measurements are in mm.

Figure 3. Bolt 5G installation drawing

## 4.3. Surface Mounting

### Before You Begin

#### Placement Considerations

For information about placement considerations, see [Required Distance Between Devices \(page 4\)](#).

#### Mounting Considerations

- Mount the Bolt 5G on a machine or cabinet.
- For information about surface heat considerations, see [Surface Heat Considerations \(page 4\)](#).
- Mounting hole diameter: M50 (50,5 mm).
- To fix the Bolt 5G position and prevent the Bolt 5G from being rotated, see [To Lock the Bolt 5G Position \(page 11\)](#).
- Bolt 5G lock nut tightening torque: 5 Nm  $\pm$ 10 %.
- Ensure to use the included housing sealing ring and lock nut.
- The top mounting surface, in contact with the sealing, must be:
  - flat with a finish equivalent to Ra 3.2 or finer.
  - cleaned and free from oils and greases.

### Mounting Procedure


1. Unscrew and remove the Bolt 5G lock nut.



2. Place the Bolt 5G housing sealing ring in its groove.




3. In the mounting surface, drill a mounting hole with the size  $\varnothing$  M50 (50,5 mm).  
Option: To fix the Bolt 5G position, see [To Lock the Bolt 5G Position \(page 11\)](#).
4. Place the Bolt 5G in its mounting hole.



5. Screw the Bolt 5G lock nut into place and tighten it.  
Tightening torque: 5 Nm  $\pm$ 10 %

**IMPORTANT**

To keep the Bolt 5G sealed against dirt and moisture, make sure the housing sealing ring is properly seated in its groove before tightening the lock nut.



## 4.4. To Lock the Bolt 5G Position

The complete surface mounting procedure is described in, [Surface Mounting \(page 8\)](#).



Figure 4. Bolt 5G steering hole for locking screw

To prevent the Bolt 5G from being rotated, use a screw and the Bolt 5G steering hole to fix the position.

### Before You Begin

Locking screw dimension: M2.5 (2,5 mm)




#### NOTE

To avoid galvanic corrosion between the screw and the Bolt 5G product housing, do not use a stainless/acid proof steel screw.

## Procedure


1. Drill a mounting hole with the size  $\varnothing$  M50 (50,5 mm) for the Bolt 5G and a hole with the size  $\varnothing$  3 mm for the locking screw.




All measurements are in mm.

Figure 5. Mounting hole and locking screw hole dimensions

2. Fasten the locking screw in the  $\varnothing$  3 mm hole.



3. Place the Bolt 5G in the surface mounting hole and fit the locking screw into the Bolt 5G steering hole.



## 4.5. Signal and Power Connector Cabling

### 4.5.1. Signal and Power Connector Pinout

An 18-pin connector cable assembly with individual wire leads is included with the product.




Table 1. 18-Pin Signal and Power Connector

Pin	Function	Color
1-14, 16	Not used	N/A
15	Power V+	Red
17	Power Ground (GND)	Black
18	Functional Earth (FE)	Green/Yellow

### 4.5.2. DC Power Interface



**IMPORTANT**

When powering the Bolt 5G, do not use PoE and DC power at the same time. Ensure to use only one source of power.



**IMPORTANT**

To prevent wires from overheating, use a power supply wire rated to carry the rated current of the Bolt 5G.

### 4.5.3. Connector Type

An 18-pin connector cable assembly with individual wire leads is included with the product.

Recommended Phoenix Contact PCB connector type:

- DFMC 0,5/ 9-ST-2,54
- DMCC 0,5/ 9-ST-2,54

## 4.6. Connect to DC Power

Option when you use DC Power. To use Power over Ethernet (PoE), see [Connect to Power Over Ethernet \(PoE\)](#).

### Before You Begin

**CAUTION**

To ensure proper functioning and electrical safety, connect the Bolt 5G Functional Earth (FE) connection to earth.

**IMPORTANT**

When powering the Bolt 5G, do not use PoE and DC power at the same time. Ensure to use only one source of power.

**NOTE**

When Bolt 5G is installed in an environment with a high level of electrical noise, use a power/Functional Earth (FE) cable with a maximum length of 3 meters.

### Power Supply Requirements

- Input voltage: 24 VDC (9 -30 VDC)
- Reverse polarity protect: Yes
- Input current: Max 625 mA @ 24 VDC
- Power consumption: Max 15 W

### Functional Earth (FE) Wire Screw Placement

When Bolt 5G is mounted on a sheet metal plate, connect Functional Earth (FE) to the plate near Bolt 5G.




Figure 6. Functional earth wire screw placement, view from below

## Procedure

### Connect to DC Power and Functional Earth (FE)




Figure 7. DC Power and Functional Earth (FE)

1. Connect Bolt 5G Power connector to Functional Earth (FE).
2. Connect Bolt 5G Power connector to a power supply.

## 4.7. Connect to Power Over Ethernet (PoE)

Option when you use Power over Ethernet (PoE). To use DC Power, see [Connect to DC Power \(page 15\)](#).

### Before You Begin



#### CAUTION

To ensure proper functioning and electrical safety, connect the Bolt 5G Functional Earth (FE) connection to earth.



#### IMPORTANT

When powering the Bolt 5G, do not use PoE and DC power at the same time. Ensure to use only one source of power.

### Power Supply Requirements

- RJ45 Power over Ethernet (PoE)
- IEEE 802.3at compliant, Type 2, Class 0
- Input voltage: 37-57 VDC
- Power consumption: Max 12.95 W

### Functional Earth (FE) Wire Screw Placement

When Bolt 5G is mounted on a sheet metal plate, connect Functional Earth (FE) to the plate near Bolt 5G.

Place one of the functional earth wire screws in the Bolt 5G steering hole.

For information about hole dimension and screw size, see [To Lock the Bolt 5G Position \(page 11\)](#).




Figure 8. Functional earth wire screw placement, view from below

## Procedure




Figure 9. Connect to Power Over Ethernet (PoE)

1. Connect the Bolt 5G to Functional Earth (FE).  
Use the Bolt 5G steering hole to connect the functional earth connection cable to the Bolt 5G.  
See [Functional Earth \(FE\) Wire Screw Placement \(page 17\)](#) and [To Lock the Bolt 5G Position \(page 11\)](#).
2. Connect the Bolt 5G Ethernet port to Ethernet/PoE.

### Ethernet RJ45 PoE Connector Pinout

RJ45 Ethernet PoE Connector	Pin	Data	PoE
	1	TP0_P	A+ Positive power from alternative A PSE
	2	TP0_N	
	3	TP1_P	A- Negative power from alternative A PSE (with pin 6)
	4	TP2_P	B+ Positive power from alternative B PSE
	5	TP2_N	
	6	TP1_N	A- Negative power from alternative A PSE (with pin 3)
	7	TP3_P	B- Negative power from alternative B PSE
	8	TP3_N	
Housing	Shield	Functional Earth (FE), via 1 nF capacitor and 1 MΩ bleeder resistor	

## 4.8. Connect to Ethernet




Figure 10. Connect to Ethernet

Connect the Bolt 5G to Ethernet network.

## 4.9. Frequency Bands and Power Level

Standard	Mode	Bands	Frequency (MHz)	Transmit Power	
UMTS (Universal Mobile Telecommunications System)	Wideband Code Division Multiple Access (WCDMA)	B1	1920 – 1980	25 dBm	
		B2	1850 – 1910		
		B4	1710 – 1755		
		B5	824 – 849		
		B8	880 – 915		
		B19	830 – 845		
LTE (Long Term Evolution)	Frequency Division Duplexing (FDD)	B1	1920 – 1980	25 dBm	
		B2	1850 – 1910		
		B3	1710 – 1785		
		B4	1710 – 1755		
		B5	824 – 849		
		B7	2500 – 2570		
		B8	880 – 915		
		B12	699 – 716		
		B13	777 – 787		
		B14	788 – 798		
		B17	704 – 716		
		B18	815 – 830		
		B19	830 – 845		
		B20	832 – 862		
		B25	1850 – 1915		
		B26	814 – 849		
	B28	703 – 748			
	B30	2305 – 2315			
	B66	1710 – 1780			
	B71	663 – 698			
	Time Division Duplex (TDD)		B34	2010 – 2025	25 dBm
			B39	1880 – 1920	
			B40	2300 – 2400	
B46			5150 – 5925		
B48			3550 – 3700	28 dBm	
B38			2570 – 2620		
B41			2496 – 2690		
B42	3400 – 3600				
B43	3600 – 3800				
5G NR (New Radio)	Non-standalone (NSA) Standalone (SA)	n1	1920 – 1980	25 dBm	
		n2	1850 – 1910		
		n3	1710 – 1785		
		n5	824 – 849		
		n7	2500 – 2570		
		n8	880 – 915		
		n12	699 – 716		
		n13	777 – 787		
		n14	788 – 798		
		n18	815 – 830		
		n20	832 – 862		
		n25	1850 – 1915		

Standard	Mode	Bands	Frequency (MHz)	Transmit Power
		n26	814 – 849	
		n28	703 – 748	
		n30	2305 – 2315	
		n48	3550 – 3700	
		n66	1710 – 1780	
		n70	1695 – 1710	
		n71	663 – 698	
		n75	698 – 716	
		n38	2570 – 2620	
		n40	2300 – 2400	
		n41	2496 – 2690	
		n77	3300 – 4200	
		n78	3300 – 3800	
		n79	4400 – 5000	

## 5. Configuration

### 5.1. Connect to Configure

#### 5.1.1. Connect to PC and DC Power

Option if you use DC Power.

When configuring Bolt 5G it must be connected to a PC.




Figure 11. Connect to PC and Power

1. Connect the Bolt 5G Ethernet port to your PC.
2. Connect the Bolt 5G Power connector to a power supply.

#### 5.1.2. Connect to PC and Power over Ethernet (PoE)

Option if you use Power over Ethernet (PoE).

When configuring Bolt 5G it must be connected to a PC.




Figure 12. Connect to PC and PoE

1. Connect the Bolt 5G Ethernet port to the PoE injector **PoE** port.
2. Connect your PC to the PoE injector **LAN** port.
3. Connect the PoE injector to a power supply.

## 5.2. Access the Built-In Web Interface

### 5.2.1. Required IP Address Settings

**NOTE**

The Bolt 5G default IP address is 192.168.0.1 and the subnet mask is 255.255.255.0.



On the PC accessing the Bolt 5G built-in web interface, set a static IP address within the same IP address range as the Bolt 5G IP address.

**Result****NOTE**

The Bolt 5G comes with a default password. You find the default password on the Bolt 5G product housing.

Now you can enter the Bolt 5G IP address in your web browser and search to access the built-in web interface login page.

## 5.2.2. Login to the Built-In Web Interface

The Bolt 5G built-in web interface can be accessed from a standard web browser.

### Before You Begin



#### IMPORTANT

For cybersecurity reasons, you are prompted to change the password at first login using the Bolt 5G factory default password. You are redirected to the **Change password** page, see [Change the Bolt 5G Password \(page 54\)](#).



#### NOTE

The Bolt 5G comes with a default password. You find the default password on the Bolt 5G product housing.



#### NOTE

The Bolt 5G default IP address is 192.168.0.1 and the subnet mask is 255.255.255.0.

### Procedure

Login to the Bolt 5G built-in web interface:

1. Open a web browser.
2. Click to select the **Address bar** and enter `https://` and the Bolt 5G IP address.



Figure 13. Enter IP address in web browser

3. Press **Enter**.  
The Bolt 5G built-in web interface login screen appears.
4. Enter **Username** and **Password** and click **Login**.




Figure 14. Built-in web interface login screen

### Result

You are logged in to the Bolt 5G built-in web interface **Home** page.




Figure 15. Home page

### 5.3. Bolt 5G Built-In Web Interface Overview

Use the Bolt 5G built-in web interface to configure, maintain and troubleshoot the Bolt 5G.




Figure 16. The Bolt 5G built-in web interface Home page

Table 2. The Bolt 5G built-in web interface menu

Menu item	Description
Home	View the current Bolt 5G settings and network status.
Cellular	Configure the cellular network, operator selection, SIM card, and APN settings.
Tunnel	Add tunnel(s) and configure the tunnel settings.
Ethernet	Configure the <b>Ethernet</b> network <b>IP Settings</b> .
Time & date	Set device time and date. Enable/Disable NTP synchronization. Enable/Disable Timezone.
System	Save settings in a configuration files, upload configuration files and upgrade firmware. Revert, reboot, or reset the Bolt 5G.
Security	Upload a web server certificate to the Bolt 5G.
Diagnostics	Monitor and troubleshoot the Bolt 5G.
Support	Contains Bolt 5G product information, Anybus contact information, link to Anybus support website, and product file for download. Here you can generate a support package with product information, to send to your Anybus support technician.
Apply	After configuration changes are made and verified, press <b>Apply</b> to make the settings take effect.

## 5.4. Factory Default Settings


Bolt 5G comes with the following factory default settings for the Ethernet interface.

Table 3. Bolt 5G Ethernet interface default settings

IP Assignment	Static
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
Internal DHCP Server	Enabled

You can restore factory default settings by making a Factory Reset. Refer to [Factory Reset Using the Reset Button](#) and [Factory Reset Using the Built-In Web Interface](#).

## 5.5. Setup Virtual Tunnel



In this example, a virtual tunnel is established between a Bolt 5G and a Tunnel Gateway to facilitate communication between a PLC and devices within a subnetwork.

Figure 17. Example, Virtual tunnel between a Bolt 5G and Bolt 5G

### Anybus Tunnel Gateway Configuration



#### NOTE

Before you start configuring the Bolt 5G, ensure you have the remote IP address for each Tunnel Gateway unit available. See also [Tunnel Settings \(page 36\)](#).

Configure and install your Anybus Tunnel Gateway unit(s) according to the Tunnel Gateway user manual.

### Ethernet Device(s) Configuration

Configure the Ethernet device(s) to be connected to the Bolt 5G and communicating with the Tunnel Gateway unit(s) according to the user documentation provided by the manufacturer.

## Bolt 5G Configuration




Figure 18. Connect the Bolt 5G to your PC and to power

### Procedure

1. Install a SIM card in the Bolt 5G SIM card holder.  
See [Install SIM Card \(page 6\)](#).
2. Connect the Bolt 5G Ethernet port to your PC.
3. Connect the Bolt 5G to power.
4. Login to the Bolt 5G built-in web interface.
5. On the **Cellular** page, configure the settings required by the 5G core network that the Bolt 5G is going to be connected to.  
See [Cellular Settings \(page 31\)](#).
6. On the **Tunnel** page, add tunnel(s) and configure the tunnel settings.  
See [Tunnel Settings \(page 36\)](#).
7. On the **Ethernet** page, configure the IP settings required by the wired network.  
See [Ethernet Settings \(page 38\)](#).
8. On the **NAT** page, configure the settings for the incoming traffic.  
See [NAT Settings \(page 39\)](#).
9. For the setting to take effect, click **Apply**.
10. Disconnect the Bolt 5G from power and your PC.

## Installation




Figure 19. Connect the Bolt 5G

### Procedure

1. Connect the Bolt 5G to power and Functional Earth (FE), see [Installation \(page 6\)](#).
2. Connect your Ethernet Device(s) to the Bolt 5G.

### Verify Connection




Figure 20. Example, tunnel status connected

On the **Home** page, you can view the connection status.

To verify the tunnel connectivity, see [Verify Operation \(page 40\)](#).

## 5.6. Cellular Settings

On the **Cellular** page, configure the operator and SIM card settings, as well as the network settings for the 5G core network that the Bolt 5G is going to be connected to.

### Before You Begin

When you are going to connect Bolt 5G to a cellular network, ensure that you have installed a SIM card in the Bolt 5G SIM card holder.

Refer to [Install SIM Card \(page 6\)](#).

### 5.6.1. Network Settings



#### NOTE

When connecting the Bolt 5G to a private stand-alone 5G network, it may be required to set 5G SA as preferred network type and to disable roaming.

By default, the **Preferred network type** is set to **Automatic**.




Figure 21. Cellular page, Network settings

Select a **Preferred network type**:

Setting	Description
Automatic	Use the Modem Preset List search order for Radio Access Technology (RAT). Connects automatically to an available network according to following priority order LTE, UMTS, GSM, and 5G mobile network. The Bolt 5G modem scans for all available Public Land Mobile Networks (PLMN) in each RAT.
UMTS, 3G	Universal Mobile Telecommunications System (UMTS) mode. Use when connecting to a UMTS network.
5G with 4G fallback	Mode for Long Term Evolution (LTE) and 5G Non-standalone (NSA). 5G NSA operates on the 4G LTE core. It is a solution for 5G networks supported by the existing 4G infrastructure. Use when connecting to LTE or non-standalone 5G networks.
5G standalone	5G Standalone (SA) mode. Use when connecting to a standalone 5G network.

## 5.6.2. Operator Selection




Figure 22. Cellular page, Operator Selection

### Automatic

By default, the **Operator** is set to **Automatic**. The mobile operator is assigned automatically.

### No Roaming

When **No roaming** is enabled, the Mobile Country Code (MCC) and Mobile Network Code (MNC) of the SIM card installed in the Bolt 5G are automatically selected.

### Manually

You can set the **Operator** manually.

The Mobile Country Code (MCC) is a unique 3-digit number to identify a country.

The Mobile Network Code (MNC) is a unique two- or three digit number assigned to a mobile network operator (MNO) within a country.

MCC 999 and MNC 99 are special codes allocated for private networks.

Example 1. MCC and MNC example

MCC for Sweden: 240

MNC assigned to the mobile network operator Telia, in Sweden: 01

## Procedure



Operator selection

Operator  
Manually

MCC  
999


MNC  
99

Figure 23. Operator settings example

1. In the **Operator** drop down menu, select **Manually**.
2. In the **MCC** field, enter the MCC code.
3. In the **MNC** field, enter the MNC code.

## 5.6.3. SIM Settings

### Activate SIM Card



Anybus® BY HMS NETWORKS

Wireless Bolt 5G ✓ Apply

Home

Configuration

Cellular

Tunnel

SIM settings

PIN-code

Figure 24. Cellular page, SIM settings

## Procedure

1. Navigate to the **Cellular** page, **SIM settings**.
2. If the SIM card installed in the Bolt 5G is locked with a PIN code, enter it in the **PIN** field. The SIM card is unlocked and the PIN code is disabled.
3. For the setting to take effect, click **Apply**.
4. On the **Home** page, you can view the SIM card status.



✓ Cellular  
Connected  
IP: 10.12.123.123  
Operator: Telia  
SIM card: OK  
SIM card state: Active  
Network type: eutran-20  
Active APN: online.telia.se  
[More information](#)

-75 dBm

Figure 25. Home page, Cellular SIM card status example

## 5.6.4. APN Settings

### APN Assignment Automatic




Figure 26. Cellular page, APN Assignment Automatic

By default, **APN assignment** is set to **Automatic**. The APN (Access Point Name) is assigned automatically.

### APN Assignment Manually

Ensure that you have the APN supplied by your carrier available.

### Procedure

APN settings

APN assignment  
Manually

APN

APN authorization  
No authorization

Figure 27. APN assignment, Manually

To set the APN assignment manually:

1. In the **APN assignment** drop down menu, select **Manually**.
2. In the **APN** field, enter the access point name.

### APN Authorization

By default, **APN authorization** is set to **No authorization**.

When enabled, the Password Authentication Protocol (PAP) authentication method is used.



#### NOTE

**APN authorization** is to be configured only if your carrier has setup APN (Access Point Name) with username and password.



#### NOTE

Ensure that you have the APN username and password supplied by your carrier available.

### Procedure

The screenshot shows the 'APN settings' page. It contains five input fields:

- APN assignment:** A dropdown menu currently showing 'Manually'.
- APN:** A text input field.
- APN authorization:** A dropdown menu currently showing 'Yes (PAP)'.
- User:** A text input field containing the text 'admin'.
- Password:** A text input field with five dots representing a password. To the right of the field is a blue eye icon, which is currently closed, indicating the password is hidden.

Figure 28. Cellular page, APN authentication Yes (PAP)

To activate APN authentication:

1. Set the **APN authorization** setting to **Yes (PAP)**.
2. In the **User** field, enter a username.
3. In the **Password** field, enter a password.
4. For the setting to take effect, click **Apply**.

## 5.7. Tunnel Settings

### Before You Begin



**NOTE**

You can add up to 8 tunnels.

### Procedure

1. On the **Tunnel** page, select the desired tunnel type: **Wireless Bolt 5G**, **Tunnel Gateway** or **Other device** from the **Add tunnel to ...** menu.




Figure 29. Add tunnel to ... menu

2. Select the tunnel and configure the **Tunnel properties**.



Figure 30. Tunnel properties panel

Setting	Value	Description
VXLAN ID	0-16777215 1, default value	Virtual Extensible LAN (VXLAN) is used to create a layer 2 network tunnel over the regular layer 3 network. VXLAN IDs enable the use of separate traffic in different virtual networks.
Remote IP	There is no default setting.	Enter the static remote IP address of the device connected to the other end of the tunnel. Write in IPv4 dot-decimal notation.
Name	There is no default Name	You can name the Tunnel to make it easier to identify. By default, the Tunnel is assigned the name Tunnel, followed by an incremental number suffix.

3. Repeat until you have added and configured all your tunnels.
4. For the setting to take effect, click **Apply**.

## 5.8. Ethernet Settings



### IMPORTANT

By default, the Bolt 5G internal DHCP server is enabled. To avoid interference, keep only one DHCP server enabled on the network.

By default, DHCP server is enabled.

This means that the IP address settings are set automatically by the Bolt 5G internal DHCP server.

To disable the DHCP server and configure the IP settings manually, deselect the **DHCP server enabled** checkbox.



Figure 31. Ethernet page

Setting	Description
IP address	The Bolt 5G network IP address. Write in IPv4 dot-decimal notation. Default: 192.168.0.1
Subnet mask	The Bolt 5G network Subnet mask. Write in IPv4 dot-decimal notation. Default: 255.255.255.0
Start IP address	Enter the first IP address of the DHCP address pool. Write in IPv4 dot-decimal notation.
End IP address	Enter the last IP address of the DHCP address pool. Write in IPv4 dot-decimal notation.

## 5.9. NAT Settings




Figure 32. NAT page, Incoming traffic menu

By default, NAT (Network Address Translation) is enabled, and **1:N** is selected in the **Incoming traffic** drop-down menu.

When 1:N is enabled:

- Multiple internal hosts are allowed to share a single publicly exposed IP address.
- All outbound traffic initiated by the local hosts destined for remote hosts is allowed.
- All incoming traffic initiated by remote hosts destined for the local hosts is rejected.

### Routing Behind Mobile Station (RBMS)

When Routing Behind Mobile Station (RBMS) is active on the mobile network, disable NAT.

To disable NAT, select **No NAT** in the **Incoming Traffic** drop-down menu.

## 6. Verify Operation

### 6.1. Bolt 5G Status Monitor




Figure 33. Home page

#### Tunnel Status

View the connection status for the tunnel(s).

#### Cellular Status

Overview of connection status, signal strength and current cellular settings.

#### Ethernet Status

View the Ethernet network communication status and IP settings.

## Status Symbols

Symbol	Description
	<p>Internal error has occurred, and operation cannot be guaranteed.</p> <p>Examples for Run Time System:</p> <ul style="list-style-type: none"> <li>• Could not initialize WLAN device management control: Could not add device management data point wlan-station/rssi: Endpoint receive operation timed out (-32603).</li> <li>• Could not initialize SystemInfo Management Control: SystemInfo: Error (-32603) adding data point system : os, Endpoint receive operation timed out.</li> <li>• Could not initialise Device Manager Control: Update DevMgmCtrl: Error (-32603) adding data point update : counter, Endpoint receive operation timed out.</li> </ul>
	Out of Specification.
	<ul style="list-style-type: none"> <li>• Power fail handling not supported.</li> <li>• Could not load and start program.</li> </ul> <p>Alerts for Cable replacement, Client:</p> <ul style="list-style-type: none"> <li>• The unit is in idle state, waiting for an event.</li> <li>• The unit is inactive.</li> <li>• The unit is disconnected.</li> <li>• The unit is restarting.</li> <li>• Incorrect password is detected.</li> </ul> <p>Alerts for Access point and Cable replacement, Access point:</p> <ul style="list-style-type: none"> <li>• The unit is disabled.</li> </ul>
	<p>Normal operation.</p> <p>Cable replacement, Client:</p> <ul style="list-style-type: none"> <li>• The unit is connected.</li> <li>• The unit is scanning.</li> </ul> <p>Access point and Cable replacement, Access point:</p> <ul style="list-style-type: none"> <li>• The unit is enabled.</li> <li>• The unit is connected to Ethernet network.</li> </ul>

## SIM Card State

State	Description
Active	SIM card installed.
N/A	No SIM card installed.

## SIM Card Status Messages

Status	Description
OK	SIM is inserted, and PIN is not required.
Absent	SIM is not inserted.
PIN Required	SIM is inserted, but PIN is required.
PUK Required	SIM is inserted, but PUK is required. The SIM needs to be unlocked by a device supporting PUK entry.
Blocked	SIM is permanently blocked.
Error	Any other error.

## 6.2. Bolt 5G LED Status Indication




Figure 34. Bolt 5G LED Indicators

	LED A	LED B	LED C	LED D	LED E	LED F
LED Status	Cellular Status	Power	SPE RX LED	SPE TX LED	IO-Link Activity LED	IO-Link Error LED
Off	Cellular modem inactive	No power	No Single Pair Ethernet (SPE) Link	No Single Pair Ethernet (SPE) link	IO-Link is inactive or no data from IO_Link device is received	IO-Link is inactive, or no error is detected
Green, solid	Connected to cellular network	Power on	SPE link active	SPE link active	N/A	N/A
Green, flashing	N/A	N/A	SPE link active and RX activity	SPE link active and TX activity	Data from IO_Link device is received	IO_Link error is detected
Green, fast flashing (once per second)	SIM not found, or PIN is required	N/A	N/A	N/A	N/A	N/A
Green, slow flashing (once per two seconds)	Searching for cellular network and trying to connect.	N/A	N/A	N/A	N/A	N/A

### 6.3. Ethernet RJ45 LED Status Indication




Figure 35. RJ45 Ethernet LED indicators

LED A – LINK/ACTIVITY	Function
Off	No Ethernet link
Yellow	Ethernet link established
Yellow, flashing	10/100/1000 Mbps Ethernet link activity

LED B – STATUS	Function
Off	No Ethernet link or 10/100 Mbps link
Green	1000 Mb/s Ethernet link established

# 7. Maintenance

## 7.1. Time & Date Settings

### 7.1.1. Set Time




Figure 36. Time & date page, Set time

You can set the current browser time and date in the Bolt 5G.

On the **Time & date** page, click **Set time**.

### 7.1.2. Network Time Protocol (NTP) Synchronization

You can use the **Network Time Protocol (NTP)** to synchronize with computer clock time sources on a network.




Figure 37. Time & date page, NTP synchronization enabled

By default, **NTP synchronization** is disabled.

To use **NTP synchronization**:

1. On the **Time & date** page, enable **NTP synchronization**.
2. In the **NTP server** fields, enter the Server name or IP number of the NTP server.  
You can enter up to four different NTP servers.
3. In the **Interval** field, enter the number of minutes between the time synchronization attempts (1-65535).

### 7.1.3. Use Timezone Settings

You can set the time zone for where the Bolt 5G is installed.




Figure 38. Time & date page, Use timezone

To set the **Use timezone**:

1. On the **Time & date** page, enable **Use timezone**.
2. In the **Timezone** menu, select the timezone where the product is installed.

## 7.2. Configuration File Handling

### 7.2.1. Export Configuration

You can export the current configuration, in order to store the configuration file as a backup or to import and use the same settings to configure additional Bolt 5G units.




Figure 39. System page

To export a configuration file:

In **System**, click **Export**.

The configuration settings are stored in a .conf file and downloaded to your PC.

## 7.2.2. Import Configuration

To configure multiple Bolt 5G units with the same settings, you can import a configuration file.

### Before You Begin

The supported file format is .conf.

### Procedure




Figure 40. System page

Import configuration file:

1. On the **System** page, click **Import**.
2. In the Import configuration window, click **Select file (.conf)**.
3. In the Open dialog box, browse to and select the configuration file and click **Open**.
4. In the Import configuration window, click **Import**.
5. The configuration file is parsed.
  - If the configuration is compatible, the settings are imported.
  - If any compatibility mismatches occur, a message about the mismatch appears.
6. To apply the settings, click **Apply** in the web-interface header, and follow the instructions.

## 7.3. Revert Configuration

You can restore all settings in a configuration to the default settings.




Figure 41. System page

When you want to remove any configuration made in a current session and re-load the configuration from the Bolt 5G.

1. On the **System** page, click **Revert**.
2. In the Confirm revert window, click **Revert**.

## 7.4. Firmware Management

### 7.4.1. View the Firmware Version

On the **Support** page, you can view the current applied firmware version.



Figure 42. Support page, Product information example

### 7.4.2. Firmware and Configuration Compatibility

#### Compatibility after Firmware Upgrade

Current configuration is still compatible after upgrading the firmware.

#### Compatibility after Firmware Downgrade

### 7.4.3. Firmware File Validation

Before the firmware file is imported into the system, the firmware upgrade function performs a validation of the file, to ensure compatibility and validity of the firmware file.

If the firmware file does not pass the validation, the firmware file is rejected, and an error message appear.

## 7.4.4. Update Firmware

### Before You Begin



#### NOTE

If the firmware update process is interrupted or if the power is lost during the update process, the update process will resume as soon as the Bolt 5G is powered on again.

### Procedure




Figure 43. System page

To update the firmware:

1. On the **System** page > **Firmware management**, click **Upload**.
2. In the Upload Firmware window, click **Select firmware (.cup)**.
3. In the Open dialog box, browse to and select the firmware file and click **Open**.
4. To start the firmware upgrade, click **Update firmware**.  
The firmware file is validated and transferred.

#### Result

- If the firmware file passes the validation: The firmware is upgraded and then the Bolt 5G automatically reboots, for the upgrade to take effect.
- If the firmware file is rejected: An error message appears.

## 7.5. Web Server Certificate Settings

Install a web server certificate in the Bolt 5G.

### Before You Begin



#### NOTE

The Web Server Certificate file must contain both Certificate and Private key.



#### NOTE

The device certificate must be a Base64 encoded DER certificate. Use the PEM (Privacy Enhanced Mail) file format.



#### NOTE

If the certificate is to be used by HTTPS, the subject name “CN” parameter must be set to the device address (IP number or DNS name).

### Procedure

1. Login to the Bolt 5G built-in web interface.
2. Navigate to the **Security** page.




Figure 44. Security page

3. To upload the web server certificate, click **Upload**.
4. In the **Upload web server certificate** window, click **Select certificate file (.pem)**.
5. In the **Open** dialog box, browse to and select the web server certificate file and click **Open > Upload certificate**.

## Result




Figure 45. Example View site information > Connection is secure

The web server certificate is uploaded in the web browser.

In the web browser **View site information**, check that the **Connection is secure**.

## 7.6. Remote Access to Bolt 5G Built-In Web GUI




Figure 46. Bolt 5G Built-In Web GUI Remote Access

By default, **Remote access to web GUI** is disabled.

To allow remote access to the Bolt 5G, click the **slide toggle**.

When **Remote access to web GUI** is enabled, you can access the Bolt 5G built-in web interface from remote hosts.

## 7.7. Change the Bolt 5G Password



### IMPORTANT

For cybersecurity reasons, you are prompted to change the password at first login using the Bolt 5G factory default password. You are redirected to the **Change password** page, see [Change the Bolt 5G Password \(page 54\)](#).

### Procedure

To change the Bolt 5G built-in web interface login password:

1. In the Bolt 5G built-in web interface header, click on the **Account** icon > **Change password**.




Figure 47. Account menu, Change password

2. Enter your current password, then enter a new password and confirm the new password.




Figure 48. Change password page

3. To make the change take effect, click **Change password**.

# 8. Troubleshooting

## 8.1. Find the Bolt 5G IP Address

You can use the software application HMS IPconfig to find the Bolt 5G IP address.

Example 2. Device IP address detected in HMS IPconfig




Figure 49. HMS IPconfig

To download the installation files, please visit [www.hms-networks.com](http://www.hms-networks.com) and enter the product article number to search for the Bolt 5G support web page. You find the product article number on the product cover.

## 8.2. Diagnostics

### 8.2.1. Event Log




Figure 50. Event log page example

To export the log data, click **Export**. An Excel XLSX file with the data is downloaded to your PC.

#### How To Analyze the Information

The log follows the FIFO principle, first in and first out. The oldest (first) value is processed first.

Value	Description
Time (d:hh:mm:ss.ms)	The date and time when the event occurred.
Message	A brief description of the event.
Type	The severity of the event occurred. For description of the symbols, see <a href="#">Status Symbols (page 41)</a> .

## 8.2.2. Commands

On the **Commands** page you find tools for network troubleshooting and management.

### Before You Begin



#### NOTE

If Bolt 5G is installed on a private cellular network, the methods are limited according to the restrictions of the private network.



#### NOTE

The methods are useful when evaluating the connection on the cellular network. Complete the evaluation by performing tests from the connected device on the LAN network.



#### NOTE

To get reliable network diagnostics results, large amounts of data may be used.

Before running the Wget method, check the SIM card data rate.

### Command Types

Command	Description
Ping	<p>Ping sends packets to the specified address and then waits for the response.</p> <p>Use ping to measure the round trip time.</p> <p>Ideally, measure towards the host that your device connects to, or another host at a similar distance. The host must be configured to respond to these types of requests.</p> <p>If errors exist, ping reports the errors.</p> <p>Ping can also show packet loss.</p> <p>If the host's IP address is known, start by pinging the host's IP address and then the host's DNS name. The DNS name is dependent on name server lookup.</p> <p>To verify that Bolt 5G is connected to internet, you can send a ping to a host or an IP number capable of returning ICMP echo responses, such as Google Public DNS.</p>
Wget	<p>Retrieve files using HTTP.</p> <p>The retrieval can help you evaluate the real download capacity of the connection. The retrieved file is not saved to the Bolt 5G.</p> <p>Wget can be used to evaluate performance. The reply message shows the elapsed time between the request being sent to the Target and the response being returned.</p>
Nslookup	<p>Nslookup is used to query internet domain name servers.</p> <p>When Nslookup is run, the IP address of the DNS server and the targeted host IP address are shown. The DNS server is usually specified by the network operator.</p>

## Procedure





Figure 51. Commands page

1. From the **Command** drop-down menu, select a command type: **Ping**, **Wget**, or **Nslookup**.
2. Enter a **Target**.
  - **Ping**: Enter the IP address (IPv4) 8.8.8.8 or 8.8.4.4.
  - **Wget**: Enter the URL of the file or directory you want to download or synchronize.
  - **Nslookup**: Enter the domain name or IP address you want to query.
3. To send the command, click **Start**.

## Result

The request is sent to the target. When the target response returns, a message appears.

Example 3. Ping response message from target 8.8.8.8



## Example 4. Nslookup response message from target webpage

Wireless Bolt 5G ✓ Apply

Article Number: Version: 1.01.00 Serial Number: 000FDD10 GUI Version: 1.10.02

### Commands

Command:

Target:

```
Tue Jul 2 07:36:51 UTC 2024, starting:
nslookup www.google.com
Server:      2.248.248.100
Address:    2.248.248.100:53

Non-authoritative answer:
Name:   www.google.com
Address: 142.250.74.36

Non-authoritative answer:
Name:   www.google.com
Address: 2a00:1450:400f:801::2004

dns finished: 0
```

## Example 5. Wget response message from target Speedtest

Wireless Bolt 5G ✓ Apply

Article Number: Version: 1.01.00 Serial Number: 000FDD06 GUI Version: 1.10.03


### Commands

Command:

Target:

```
Tue Jul 9 06:20:12 UTC 2024, starting: time
wget -T 30 speedtest.ftp.otenet.gr/files/
test100k.db
[0] Downloading 'http://speedtest.ftp.otenet.gr/
files/test100k.db' ...
HTTP response 200 OK [http://
speedtest.ftp.otenet.gr/files/test100k.db]
wget finished: 0
```

### Example 6. Wget response message from target webpage



The screenshot shows the 'Wireless Bolt 5G' application interface. At the top, there is a header with the device name and an 'Apply' button. Below the header, the 'Commands' section is visible. It contains a 'Command' dropdown menu set to 'Wget', a 'Target' text input field containing 'www.google.com', and a 'Start' button with a right-pointing arrow. Below the configuration fields is a terminal window displaying the following output:

```
Tue Jul 2 07:40:49 UTC 2024, starting: time
wget -T 30 www.google.com
Failed to open tmpfile './.local/share/
wget/.wget-ocsp_hostsyM4N5M' (2)
Failed to write to OCSP hosts to './.local/
share/wget/.wget-ocsp_hosts'
Failed to open tmpfile './.local/share/
wget/.wget-ocspKtofGt' (2)
Failed to write to OCSP fingerprints to
 './.local/share/wget/.wget-ocsp'
[0] Downloading 'http://www.google.com' ...
HTTP response 200 OK [http://www.google.com]
wget finished: 0
```

Response message with elapsed time between the request being sent to the Target and the response being returned.

### 8.2.3. History Monitor

On the **History monitor** page, you can view the status over time for the Connection State, Signal Strength, and Amplifier Temperature.



Figure 52. History monitor page

## 8.3. Reboot Using the Built-In Web Interface

### Before You Begin

During reboot, the Bolt 5G is temporarily unavailable for approximately two minutes.

### Procedure

1. Ensure that the Bolt 5G is powered on and running.




Figure 53. Power on the Bolt 5G

2. Login to the Bolt 5G built-in web interface.
3. On the **System** page, click **Reboot**.




Figure 54. System page, Reboot

4. To confirm the reboot, click **Reboot**.




Figure 55. Confirm reboot

## Result

You are logged out of the Bolt 5G built-in web interface and redirected to the login page.

## 8.4. Reboot Using the Reset Button

### Before You Begin

During reboot, the Bolt 5G is temporarily unavailable for approximately two minutes.

### Procedure

To reboot the Bolt 5G:

1. Ensure that the Bolt 5G is powered on.




Figure 56. Power on the Bolt 5G

2. Use a pointed object, such as a paper clip, to press and hold the **Reset** button.




Figure 57. Press and hold **Reset** button

3. When the LED status indicators have flashed 3 times, release the **Reset** button, and wait while the Bolt 5G reboots.




Figure 58. Release **Reset** button after the LED indicators have flashed 3 times

#### Result

You are logged out of the Bolt 5G built-in web interface and redirected to the login page.

## 8.5. Reset Using the Built-In Web Interface

### Procedure

1. Ensure that the Bolt 5G is powered on and running.




Figure 59. Power on the Bolt 5G

2. Log in to the Bolt 5G built-in web interface.
3. On the **System** page, click **Factory default reset**.




Figure 60. System page, Factory default reset

- To confirm the factory default reset, click **Reset**.




Figure 61. Confirm factory default reset

## Result

You are logged out of the Bolt 5G built-in web interface and redirected to the login page.

When the Bolt 5G has successfully rebooted, the Bolt 5G configuration is reset to the factory default configuration.

## 8.6. Reset Using the Reset Button



### IMPORTANT

Factory Reset will result in the loss of all configuration settings and logs.

1. Ensure that the Bolt 5G is powered on and running.




Figure 62. Power on the Bolt 5G

2. Use a pointed object, such as a paper clip, to press and hold the **Reset** button for >7 seconds. When the **Reset** button is pressed, the Bolt 5G LED status indicators start flashing slowly. After 7 seconds the rate increases, then release the reset button.



### NOTE

Pressing the **Reset** button twice in a row will reboot the Bolt 5G without factory reset.




Figure 63. Reset button

### Result

Bolt 5G is reset to the factory default settings.

## 9. Technical Data

### 9.1. Technical Specifications

Additional technical data and information related to the installation and use of this product can be found at [www.hms-networks.com](http://www.hms-networks.com).

Model identification	NV200
Communication connector	RJ45 Ethernet 10/100/1000 Mbit/s, PoE
Signal and power connector	18-Pin signal and power connector, Phoenix Contact PCB connector DFMC 0,5/ 9-ST-2,54
Power supply, PoE	RJ45 Power over Ethernet (PoE) Input voltage: 37-57 VDC
Power supply, DC power	Input voltage: 24 VDC (9-30 VDC) Reverse voltage protection Input current: Max 625 mA @ 24 VDC Reverse polarity protect: Yes IEEE 802.3at compliant, Type 2, Class 0
Single Pair Ethernet (SPE) connector	2P2C SPE, IEEE802.3bw 100BASE-T1 Ethernet
Power consumption, PoE	Max 12.95 W
Power consumption, DC power	Max 15 W
Power over Ethernet (PoE)	44-57 VDC DTE Type1 according to IEEE 802.3af
Antenna	4 internal antennas
Frequency bands	See <a href="#">Frequency Bands and Power Level (page 20)</a> .
Storage temperature	-40 to +85 °C
Operating temperature	-40 to +70 °C
Humidity	EN 60068-2-78: Damp heat, +40°C, 90% Non-condensing
Housing material	Plastic (see data sheet for details) Aluminum (see data sheet for details)
Protection class	Top (outside of host): IP66 Base (inside of host): IP32
Product weight	300 g
Dimensions	Height: 87 mm Diameter Bottom: 50 mm Top: 114 mm
Mounting	M50 screw and nut. 50.5 mm hole needed. Locking screw M2.5 (2,5 mm)