

Anybus[®] Communicator[™] - Modbus RTU Server to PROFIBUS USER MANUAL

SCM-1202-243
Version 1.0
Publication date 2025-04-25



Important User Information

Disclaimer

The information in this document is for informational purposes only. Please inform HMS Networks of any inaccuracies or omissions found in this document. HMS Networks disclaims any responsibility or liability for any errors that may appear in this document.

HMS Networks reserves the right to modify its products in line with its policy of continuous product development. The information in this document shall therefore not be construed as a commitment on the part of HMS Networks and is subject to change without notice. HMS Networks makes no commitment to update or keep current the information in this document.

The data, examples and illustrations found in this document are included for illustrative purposes and are only intended to help improve understanding of the functionality and handling of the product. In view of the wide range of possible applications of the product, and because of the many variables and requirements associated with any particular implementation, HMS Networks cannot assume responsibility or liability for actual use based on the data, examples or illustrations included in this document nor for any damages incurred during installation of the product. Those responsible for the use of the product must acquire sufficient knowledge in order to ensure that the product is used correctly in their specific application and that the application meets all performance and safety requirements including any applicable laws, regulations, codes and standards. Further, HMS Networks will under no circumstances assume liability or responsibility for any problems that may arise as a result from the use of undocumented features or functional side effects found outside the documented scope of the product. The effects caused by any direct or indirect use of such aspects of the product are undefined and may include e.g. compatibility issues and stability issues.

Copyright © 2025 HMS Networks

Contact Information

Postal address:

Box 4126

300 04 Halmstad, Sweden

E-Mail: info@hms.se

Table of Contents

1. Preface	1
1.1. About This Document	1
1.2. Document Conventions	1
1.3. Trademarks	2
2. Safety	3
2.1. Intended Use	3
2.2. General Safety	3
3. Cybersecurity	4
3.1. General Cybersecurity	4
3.2. Security Advisories	4
3.3. How to Report a Vulnerability	4
3.4. Product Cybersecurity Context	5
3.4.1. Security Defense in Depth Strategy	5
3.4.2. Purdue Model	6
4. Preparation	7
4.1. Support and Resources	7
4.2. Cabling	7
4.3. Mechanical Tools and Equipment	7
4.4. System Requirements	7
4.4.1. Supported Operating Systems	7
4.4.2. Supported Web Browsers	7
4.5. HMS Software Applications	8
4.6. Third-Party Software Applications	8
4.7. Software License Information	8
5. About Anybus Communicator	9
5.1. How the Communication Works	9
5.2. How the Data Exchange Works	10
5.3. Data Integrity	10
6. Installation	11
6.1. External Parts	11
6.2. Connector Port Guide	12
6.3. DIN Rail Mounting	13
6.4. Connect to Modbus RTU Network	14
6.5. Connect to PROFIBUS Network	16
6.6. Rotary Switch Settings	17
6.6.1. Rotary Switches Default Setting	17
6.6.2. Set a Node Address with Rotary Switches	18
6.7. Connect to Power	22
6.8. Security Switch	23
6.9. Lock the Cables	25
6.10. DIN Rail Demount	26
7. Communicator Configuration	28
7.1. Modbus RTU Settings	28
7.1.1. Communication Settings	28
7.1.2. Legacy Mode for Anybus Address Mode Modbus RTU	30
7.2. PROFIBUS Settings	31

7.2.1. PROFIBUS Address Settings	31
7.2.2. Legacy Mode for PROFIBUS General Station Description (GSD) File	32
7.2.3. Allow Any Module Mapping for PROFIBUS	33
7.3. I/O Configuration	35
7.3.1. Endian Swap	35
7.3.2. Convert Between Big-Endian and Little-Endian	36
7.3.3. Build Detailed Endian Swap	37
7.3.4. Process Data Settings	38
7.4. Configuration Notes	39
7.4.1. Add Configuration Note	39
7.4.2. View and Edit Configuration Notes	41
7.5. Apply Configuration	42
7.6. To Use an Existing Configuration	43
8. PLC Configuration	44
8.1. PLC Device Security	44
8.2. Export Product GSD File	44
8.3. Modbus Addressing and Register Mapping	45
8.3.1. The Difference Between Address and Register Start	45
8.3.2. To Read and Write Data	46
8.3.3. Default Address Mode I/O Data Mapping	48
8.3.4. Legacy Address Mode I/O Data Mapping	49
9. Verify Operation	50
9.1. Communicator Status Monitor	50
9.2. Communicator LED Indicators	52
9.3. Ethernet LED Indicators	53
10. Maintenance	54
10.1. Action on Fatal Error	54
10.2. Configuration Port IP Settings	55
10.3. Configuration File Handling	56
10.3.1. Export Configuration	56
10.3.2. Import Configuration	57
10.4. Clear and Revert Configuration	58
10.5. Firmware Management	59
10.5.1. View the Firmware Version	59
10.5.2. Firmware and Configuration Compatibility	59
10.5.3. Firmware File Validation	59
10.5.4. Update Firmware	60
10.6. Change Language	61
11. Troubleshooting	62
11.1. Diagnostics	62
11.1.1. I/O Data	62
11.1.2. Event Log	63
11.1.3. LED Status	64
11.2. Reset to Factory Settings	65
11.3. Firmware Upgrade Error Management	68
11.4. Support	70
11.4.1. Support Package	70
12. Technical Data	71
12.1. Technical Specifications	71

13. End Product Life Cycle	72
13.1. Secure Data Disposal	72
14. Reference Guides	73
14.1. About Input Registers and Holding Registers	73
14.2. Modbus Data Model	73
14.3. Modbus Function Codes	74
14.4. Modbus Exception Codes	74

This page is intentionally left blank.

1. Preface

1.1. About This Document

This document describes how to install and configure Anybus® Communicator™.

For additional documentation and software downloads, FAQs, troubleshooting guides and technical support, please visit www.hms-networks.com/technical-support.

1.2. Document Conventions

Lists

Numbered lists indicate tasks that should be carried out in sequence:

1. First do this
2. Then do this

Bulleted lists are used for:

- Tasks that can be carried out in any order
- Itemized information

User Interaction Elements

User interaction elements (buttons etc.) are indicated with bold text.

Program Code and Scripts

```
Program code and script examples
```

Cross-References and Links

Cross-reference within this document: [Document Conventions \(page 1\)](#)

External link (URL): www.hms-networks.com

Safety Symbols



DANGER

Instructions that must be followed to avoid an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

Instructions that must be followed to avoid a potential hazardous situation that, if not avoided, could result in death or serious injury.



CAUTION

Instruction that must be followed to avoid a potential hazardous situation that, if not avoided, could result in minor or moderate injury.



IMPORTANT

Instruction that must be followed to avoid a risk of reduced functionality and/or damage to the equipment, or to avoid a network security risk.

Information Symbols

**NOTE**

Additional information which may facilitate installation and/or operation.

**TIP**

Helpful advice and suggestions.

1.3. Trademarks

Anybus® is a registered trademark of HMS Networks.

All other trademarks are the property of their respective holders.

2. Safety

2.1. Intended Use

The intended use of this equipment is as a communication interface and gateway.

The equipment receives and transmits data on various physical layers and connection types.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

2.2. General Safety

**CAUTION**

Ensure that the power supply is turned off before connecting it to the equipment.

**CAUTION**

This equipment contains parts that can be damaged by electrostatic discharge (ESD). Use ESD prevention measures to avoid damage.

**CAUTION**

To avoid system damage, the equipment should be connected to ground.

**IMPORTANT**

Using the wrong type of power supply can damage the equipment. Ensure that the power supply is connected properly and of the recommended type.

3. Cybersecurity

3.1. General Cybersecurity

**IMPORTANT**

It is important to maintain the cybersecurity of the Communicator.

Before connecting the Communicator to a PLC, ensure the PLC is configured and installed in accordance with the PLC supplier hardening guidelines.

**IMPORTANT**

To physically secure networks and equipment and to prevent unauthorized access, it is recommended to install the equipment in a locked environment.

**IMPORTANT**

After completing the configuration of the Communicator, lock the security switch to prevent unauthorized access to the Communicator built-in web interface.

**IMPORTANT**

To avoid exposure of sensitive data, always perform a factory reset before decommissioning the equipment.

Factory reset will reset any on site made configuration changes and set the Communicator to the same state as leaving HMS production.

See [Reset to Factory Settings \(page 65\)](#).

3.2. Security Advisories

For cybersecurity reasons, stay informed about new vulnerabilities and follow the recommended actions.

HMS Networks Security Advisories includes information about our product vulnerabilities and available solutions.

You find our Safety Advisories at www.hms-networks.com/cybersecurity/security-advisories.

3.3. How to Report a Vulnerability

HMS Networks place the utmost importance on the security of our products and systems, however, despite all the measures we take, it cannot be excluded that vulnerabilities persist.

To report a potential vulnerability in an HMS product or service, please visit www.hms-networks.com/cybersecurity/report-a-vulnerability and follow the instructions.

3.4. Product Cybersecurity Context

3.4.1. Security Defense in Depth Strategy

The defense in depth strategy of the Communicator includes the following security measures:

- Secure Boot: Security standard used to ensure that the Communicator boots using only software that is trusted by HMS Networks.
- Signed firmware: HMS Networks delivers digitally signed firmware. Before the firmware file is imported into the Communicator, the firmware upgrade function performs a validation of the file, to ensure that is authentic.
- Security switch: Used to lock unauthorized access to the Communicator built-in web interface.
- The Communicator is intended to be installed in a Process Control Network (PCN) environment. See Level 1 in the [Purdue Model \(page 6\)](#).
- To physically secure networks and equipment and to prevent unauthorized access, the Communicator is intended to be installed in a locked environment.

3.4.2. Purdue Model

The Communicator is intended to be part of the process control network in Level 1 (E), to enable communication between PLCs or between a PLC and peripheral devices.




Figure 1. Purdue model, product security context

IT Network

- A. **Level 4: Enterprise Network**
Example: Cloud solution, Business LAN (VPN)
- B. **Level 3.5: Perimeter Network**
Example: Demilitarized Zone (DMZ)

OT Network

- C. **Level 3: Advanced Control Network (ACN)**
Example: SCADA systems, Business control
- D. **Level 2: Supervisory Control**
Example: Operator panels, Operator stations, Engineering stations
- E. **Level 1: Process Control Network (PCN)**
Environment where the Communicator is installed
Example: Factory floor, Industrial product line

4. Preparation

4.1. Support and Resources

For additional documentation and software downloads, FAQs, troubleshooting guides and technical support, please visit www.hms-networks.com/technical-support.

**TIP**

Have the product article number available, to search for the product specific support web page. You find the product article number on the product cover.

4.2. Cabling

Have the following cables available:

- Power cable.
- Ethernet cable for configuration.
- PROFIBUS cable for connecting to network.
- 7-pin screw terminal block connector is included with the product.

4.3. Mechanical Tools and Equipment

Have the following tools available:

- Flat-head screwdriver, size 5.5 mm
Needed when removing the Communicator from DIN-rail.
Needed when changing the position of the rotary switches.
- Flat-head screwdriver, size 3 mm
Needed when connecting the cables to the 7-pin connector.

4.4. System Requirements

4.4.1. Supported Operating Systems

Operating System	Description
Windows 7 SP1, 32-bit	Windows 7 32-bit with Service Pack 1
Windows 7 SP1, 64-bit	Windows 7 64-bit with Service Pack 1
Windows 10 64-bit	Windows 10 64-bit
Windows 11 64-bit	Windows 11 64-bit

4.4.2. Supported Web Browsers

The Communicator built-in web interface can be accessed from the following standard web browsers.

- Google Chrome
- Microsoft Edge
- Mozilla Firefox

4.5. HMS Software Applications

Download the software installation files and user documentation from www.hms-networks.com/technical-support.

HMS IPconfig

Use the software application HMS IPconfig and scan your network to discover and change the Communicator IP address and to access the Communicator built-in web interface.

**NOTE**

As an alternative, you can set a static IP address within the same IP address range as the Communicator IP address on the computer accessing the Communicator built-in web interface.

**NOTE**

HMS IPconfig is only available for Windows.

4.6. Third-Party Software Applications

Microsoft Excel

Microsoft Excel, or equivalent software application that supports the Office Open XML Workbook (xlsx) file format. Needed to open and read the **Event log** file.

4.7. Software License Information

For license agreements regarding the third-party software used in the Communicator, refer to the *LICENSE.txt* file(s) included in the Communicator firmware update package zip file.

To download the Communicator firmware update package zip file, please visit www.hms-networks.com/technical-support.

**TIP**

Have the product article number available, to search for the product specific support web page. You find the product article number on the product cover.

5. About Anybus Communicator

5.1. How the Communication Works




Figure 2. Process data traffic overview

The Communicator enables communication between a Client device connected to a Modbus RTU network and a Client device connected to a PROFIBUS network.

The Client device can, for example, be a PLC control system or a Gateway.

The Communicator main task is to transfer cyclic I/O data between the two networks.

5.2. How the Data Exchange Works




Figure 3. The Communicator internal memory areas

The data exchanged between the Communicator and the Modbus RTU and the PROFIBUS resides in the Communicator internal memory buffer.

Input Data

This Input data area is read by the PROFIBUS.

Output Data

The Output data area is read/written by the Modbus RTU.

5.3. Data Integrity

A snapshot of the process data buffer between the Client and the server interface is used during the operation of executing all the transactions within one cycle.

When the cycle is completed, the process data available on the server interface is updated and a new snapshot is created for the next cycle.

6. Installation

6.1. External Parts




Figure 4. External parts

- | | | |
|--|--|--|
| A. Power connector | F. 7-pin connector | J. Security switch |
| B. Rotary Switch x 3
For PROFIBUS address | G. PROFIBUS DSUB connector | K. Factory reset button |
| C. Label with LED designation | H. Cable tie mount | L. Laser engraved label with product information |
| D. Status LEDs | I. Laser engraved connectors designation | M. DIN rail locking mechanism |
| E. Configuration port | | |

6.2. Connector Port Guide




Figure 5. Communicator connector ports

Position	Port Number	Connector Type	Port Usage
A	X1	Ethernet RJ45	Configuration port
B	X2	7 Pin Screw Terminal Block	Modbus RTU network
C	X3	D-SUB	PROFIBUS network

See also [Connect to Modbus RTU Network](#) and [Connect to PROFIBUS Network \(page 16\)](#).

6.3. DIN Rail Mounting

**IMPORTANT**

The equipment must be electrically grounded through the DIN rail for EMC compliance. Make sure that the equipment is correctly mounted on the rail and that the rail is properly grounded.

**IMPORTANT**

To physically secure networks and equipment and to prevent unauthorized access, it is recommended to install the equipment in a locked environment.




Figure 6. Attach the Communicator on the DIN rail

To attach the Communicator on the DIN rail:

1. Insert the upper end of the DIN rail clip into the DIN rail.
2. Push the bottom of the DIN rail clip into the DIN rail.

6.4. Connect to Modbus RTU Network

**NOTE**

Use minimum 90 oC copper (Cu) wire only.




Figure 7. Connect to Modbus RTU network


Procedure

1. Insert the cable wires into the 7-pin connector and tighten the wire clamp screws.
2. Connect the 7-pin connector to the Communicator.
3. Connect the Communicator to your Modbus RTU network.

Modbus RTU Serial Connector Pinout



NOTE
Use minimum 90 oC copper (Cu) wire only.

7-pin connector	Pin	Signal
	1	+5 V OUT
	2	RS485+ A
	3	RS485- B
	4	Signal GND
	5	Functional Earth (FE)
	6	RS232 Tx Transmit Data
	7	RS232 Rx Receive Data

6.5. Connect to PROFIBUS Network




Figure 8. Connect to PROFIBUS network

Connect the Communicator, lower connector, to your PROFIBUS network.

PROFIBUS D-SUB Connector Pinout

PROFIBUS Connector	Pin	Description
	1	Not used
	2	Not used
	3	Line B
	4	RTS
	5	GND Bus
	6	+5 V Bus Out
	7	Not used
	8	Line A
	9	Not used
	Housing	PE

6.6. Rotary Switch Settings

6.6.1. Rotary Switches Default Setting

By default, the value on the three rotary switches are set to **000**.




Figure 9. Rotary switches default setting **000**.


6.6.2. Set a Node Address with Rotary Switches

About the Rotary Switch Settings

**TIP**

Use Windows Calculator (or similar application) to convert between hexadecimal (hex) and decimal (dec).

- The default node address setting is 000.
- When the node address setting is 000, you can set the node address via the Communicator built-in web interface.
See [PROFIBUS Address Settings \(page 31\)](#).
- The node address values are set in hexadecimal (hex).
- Minimum value is 00.
- Supports PROFIBUS node addresses 0-126 Dec (0-7E Hex).
- Each node address may only occur once in the network.
- The node address is read from the center rotary switch x16 to the front rotary switch x1.
- The rear rotary switch is not used, ensure that it is set to 0.



Before You Begin

Ensure that the Communicator is disconnected from power.





Figure 10. Disconnect Communicator from power


Procedure

Use a screwdriver to change the rotary switch position.

Ensure that the rotary switches engage correctly.



Example 1. To set the node address 12 hex = 18 dec



1. The rear rotary switch A is not used, ensure that it is set to 0.
2. Set the center rotary switch B to 1 hex.
3. Set the front rotary switch C to 2 hex.

The center rotary switch B 1 hex = 1 dec and the front rotary switch C 2 hex = 2 dec.

The node address expressed in decimal numbers is therefore $16 \times 1 + 2 = 18$.

To Do Next

Connect the Communicator to power. See [Connect to Power \(page 22\)](#).




Figure 11. Connect Communicator to power

Result

The set node address is active as soon as the Communicator is powered on.

**NOTE**

Changing the address settings on the rotary switches during operation is ignored. For a new address to take effect, power cycle the Communicator.

6.7. Connect to Power



CAUTION
Ensure that the power supply is turned off before connecting it to the equipment.



IMPORTANT
Using the wrong type of power supply can damage the equipment. Ensure that the power supply is connected properly and of the recommended type.



IMPORTANT
Before you connect the Communicator to power, ensure that the PROFIBUS address is set on the rotary switches. If the PROFIBUS address is set when the Communicator is operating, you must power cycle the Communicator for the new setting to take effect.




Figure 12. Connect to power

Power Connector Pinout

Power port	Pin	Description
	1	12-30 VDC Power Connector
	2	Ground (GND)
	3	Functional Earth (FE)

Procedure

1. Insert the cable wires to the terminal block and tighten the wire clamp screws.
2. Connect the terminal block to the Communicator.
3. Connect the Communicator to a power supply.
4. Turn on the power supply.

6.8. Security Switch



IMPORTANT

After completing the configuration of the Communicator, lock the security switch to prevent unauthorized access to the Communicator built-in web interface.

When the security switch is in its locked position, the Communicator built-in web interface cannot be accessed, and the Communicator cannot be configured using the built-in web interface. Network specific parameters, configured via the PLC is still available.

To Lock and Unlock the Security Switch




Figure 13. Security switch in locked and unlocked position

Use a pointed object, such as a ballpoint pen.

- To **lock** the security switch, push the toggle towards the **Communicator front**.
- To **unlock** the security switch, push the toggle towards the **Communicator back**.

Security Switch Status LED




Figure 14. Security switch locked status LED

When the security switch is in its:

- locked position, the security switch status LED turn solid green.
- unlocked position, the security switch status LED is turned off.

6.9. Lock the Cables




Figure 15. Lock the cables

To strain relieve the cables, place a cable tie in the holder and lock the cables.

6.10. DIN Rail Demount

Before You Begin



IMPORTANT

Be careful when removing the Communicator from the DIN-rail. If not removed properly, the DIN rail locking mechanism and the product cover can break.

Have a flat-blade screwdriver, size 5.5 mm, available.

Procedure

Remove the Communicator from the DIN rail:

1. Insert the screwdriver into the Communicator DIN rail locking mechanism.
2. To unlock the Communicator DIN rail locking mechanism, turn the screwdriver clockwise.




Figure 16. Unlock the Communicator

3. Hold the screwdriver in the DIN rail locking mechanism while you unhook the Communicator from the DIN rail.




Figure 17. Unhook the Communicator

7. Communicator Configuration

7.1. Modbus RTU Settings

7.1.1. Communication Settings

Anybus Communicator

Article Number: ABCXXXXX Version: 1.02.03 Serial Number: ABC123456 GUI Version: 1.22.01

✓ Apply

Modbus RTU (X2)

Communication settings

Node address*

7

Physical stand

RS-232

Baud rate

9600 baud

Stop bits

1 stop bit

Parity

None

Timeout times

Process data active timeout*

0

ms

Figure 18. Communication, Basic settings



Node Address

Enter the **Node address** for the Modbus RTU server connected to the Communicator.

Physical Standard

Specify the physical interface type for the Modbus RTU network.

Select a physical standard from the **Physical standard** drop-down menu.

Setting	Value	Description
Physical standard	RS-232, Default standard	Use RS-232 when one single device is connected to the network. 
	RS-485	Use RS-485 when multiple devices are connected to the network. 

Baud Rate

Specify the baud rate; the serial transfer speed, maximum bits per second.

Select a baud rate value from the **Baud rate** drop-down menu.

Setting	Value
Baud rate	1200 baud
	1800 baud
	2400 baud
	4800 baud
	9600 baud, Default value
	19200 baud
	35700 baud
	38400 baud
	57600 baud
	115200 baud
	128000 baud

Stop Bits

Specify the number of stop bits used to indicate the end of data transmission.

Select a stop bits value from the **Stop bits** drop-down menu.

Setting	Value
Stop bits	1 stop bit, Default value
	2 stop bit

Parity

Specify if parity should be used to detect errors in the data.

Select parity value from the **Parity** drop-down menu.

Setting	Value	Description
Parity	None, Default value	No parity checking Parity bit is not transmitted
	Odd	Odd parity checking
	Even	Even parity checking

Timeout Times**Process Data Active Timeout**

Specify the maximum allowed time between two incoming messages in steps of 10 ms.

To enable **Process data active timeout**, enter a value between 1 and 65535 milliseconds (ms).

If this time is exceeded, the Modbus RTU network is considered to be offline.

The data sent to the PROFIBUS network is frozen.

To enable clear data, see [Process Data Settings \(page 38\)](#).

A value of 0 disables this feature, i.e. the Modbus RTU network can never go offline.

The default value is 0 ms.

Apply Configuration

To apply the settings, click **Apply** in the built-in web interface header and follow the instructions.

7.1.2. Legacy Mode for Anybus Address Mode | Modbus RTU

Advanced settings option for Modbus RTU Server.

About Legacy Mode

Use Legacy Mode when you want to make a new Communicator compatible with the X-gateway Anybus Address Mode.

See also [Legacy Address Mode I/O Data Mapping \(page 49\)](#).

To Use Legacy Mode




Figure 19. Advanced settings > Use legacy mode

To enable Legacy mode, select the **Use legacy mode** checkbox.

7.2. PROFIBUS Settings

7.2.1. PROFIBUS Address Settings



NOTE

Ensure that the Communicator rotary switches are sett to 000.




Figure 20. PROFIBUS address setting

In the PROFIBUS address field, enter the Communicator node address.

7.2.2. Legacy Mode for PROFIBUS General Station Description (GSD) File

Before You Begin



IMPORTANT

Legacy mode does not support acyclic communication.



NOTE

When Use legacy mode is enabled for PROFIBUS, **Allow any module mapping** is automatically enabled. When **Allow any module mapping** is enabled, the **Diagnostics** functionality is limited.

If you already have an Anybus X-gateway device description file installed in your PLC, legacy mode allows you to continue using the settings from the device description file for the new Communicator.

Procedure

GSD file

GSD file

⚠ Not applicable in Legacy mode. Uses the already installed ABX Classic GSD file.

Advanced settings

☒ Use legacy mode

Use the legacy mode to force the product into being compatible to how the previous generation product behaved.

☒ Allow any module mapping

When you allow any module mapping diagnostics is limited.

Figure 21. Advanced settings > Use legacy mode and Allow any module mapping

To enable the legacy mode, select the **Use legacy mode** checkbox.

When Use legacy mode is enabled, the device description file download becomes inactive.

Legacy mode for PROFIBUS includes the **Allow any module mapping** setting, which is automatically enabled when you select the **Use legacy mode** checkbox.

See [Allow Any Module Mapping for PROFIBUS \(page 33\)](#).

7.2.3. Allow Any Module Mapping for PROFIBUS

Advanced settings option for PROFIBUS.

Before You Begin



NOTE

When Allow any module mapping is enabled, the **Diagnostics** functionality is limited.



NOTE

When Allow any module mapping is enabled, the **I/O configuration** I/O size setting for **PROFIBUS** is restricted.

For more information, see [I/O Size Restrictions for Allow Any Module Mapping](#).

Allow any module mapping has fewer restrictions and allows the modules to be mapped in any slot.

Option 1 - Use Legacy Mode and Allow any Module Mapping Enabled

Procedure

GSD file

GSD file

Not applicable in Legacy mode. Uses the already installed ABX Classic GSD file.

Advanced settings

☒ Use legacy mode
Use the legacy mode to force the product into being compatible to how the previous generation product behaved.

☒ Allow any module mapping
When you allow any module mapping diagnostics is limited.

Figure 22. Advanced settings, **Use legacy mode** and **Allow any module mapping** is enabled

When **Use legacy mode** is enabled **Allow any module mapping** is automatically enabled.

Option 2 - Allow Any Module Mapping Enabled

GSD File Compatible With Allow Any Module Mapping



NOTE

If you are replacing an X-gateway with a new Communicator and already have the *HMSA183B.gsd* installed in the PLC to be connected to the Communicator, you do not need to reinstall the file.



NOTE

When the *HMSB183B.gsd* file is used, the Communicator cannot provide diagnosis data. The **Diagnostics** functionality becomes inactive.

When only the **Allow any Module Mapping** is enabled, use the GSD file named *HMSB183B.gsd* to configure the PLC connected to the Communicator.

The *HMSB183B.gsd* file:

- Contains no slot definitions.
- Allows the modules to be plugged into any slot.
- Allows the same type of module to be used multiple times.

See also [Export Product GSD File \(page 44\)](#).

Procedure




Figure 23. Advanced settings, **Allow any Module Mapping** is enabled

To enable any module mapping, select the **Allow any module mapping** checkbox.

7.3. I/O Configuration




Figure 24. I/O configuration page

Enter the desired **Size** for the network input data and output data.

By default, the Communicator is set to use the same I/O sizes for both the Modbus RTU and the PROFIBUS networks.

To configure different sizes for the networks, deselect the **Same I/O sizes for both networks** checkbox.

7.3.1. Endian Swap

By default, Communicator uses **No swapping**.

About Endianness

Big-endian (BE)

The big-endian format places the most significant byte of the data at the byte with the lowest memory address.

Little-endian (LE)

The little-endian format places the least significant byte of the data at the byte with the lowest memory address.

7.3.2. Convert Between Big-Endian and Little-Endian

To convert between big-endian and little-endian you must reverse the byte order.




Figure 25. I/O configuration page, Endian swap

To reverse the byte order:

1. In the web-interface left sidebar menu, click **I/O configuration**.
2. In the data map, select the connection for which you want to do swap the byte order.
3. Select the endian swap type from the **Endian swap** drop-down menu.

Setting	Description
No swapping	Default setting No swapping is performed on the data.
Bytes	Swap 2 bytes A B C D becomes B A D C
Words	Swap 4 bytes A B C D becomes C D A B
Bytes and words	A B C D becomes D C B A
Detailed swap	With Detailed swap, you can select an Endian swap method for each byte in the I/O Configuration. Set the endian swap type No swap , Bytes, AB → BA , Word swap, ABCD → CDAB or Bytes and words, ABCD → DCBA for each bite. See Build Detailed Endian Swap (page 37) .

4. To apply the settings, click **Apply** in the web-interface header, and follow the instructions.

7.3.3. Build Detailed Endian Swap

If you have multiple data types, you can use the **Detailed endian swap** to change different parts of the data area in different ways.




Figure 26. Detailed endian swap example

1. In the **Endian swap** drop-down menu for the desired network(s), select **Detailed swap**.
2. Build the detailed endian swap.
 - To add an endian swap object: Drag and drop the desired endian swap object from the toolbar into the drag and drop fields.
 - To duplicate an endian swap object: Select the checkbox in front of the endian swap object that you want to duplicate and click the **Duplicate selected** button.
You can select multiple endian swap objects and duplicate the group.
 - To change the order of the endian swap objects, drag and drop the endian swap objects in the list.

7.3.4. Process Data Settings

The screenshot shows the 'Anybus Communicator' I/O configuration interface. The left sidebar contains navigation links: Home, Configuration (Modbus RTU (X2), PROFIBUS (X3), I/O configuration), Maintenance (System, Files & firmware), and Troubleshooting (Diagnostics, Support). The main area is titled 'I/O configuration' and features a diagram of a Modbus RTU (X2) unit connected to a PROFIBUS (X3) unit. Below the diagram, there are two rows of settings for data exchange. The first row is for 'From Modbus RTU (X2) to PROFIBUS (X3)' and the second is for 'To Modbus RTU (X2) from PROFIBUS (X3)'. Each row has a 'Size*' field set to '20 bytes' and an 'Endian swap' dropdown set to 'No swapping'. A checkbox labeled 'Same I/O sizes for both networks.' is checked. Below these, there are two columns of settings: 'Modbus RTU status byte' and 'Clear data when Modbus RTU offline' on the left, and 'PROFIBUS status byte' and 'Clear data when PROFIBUS offline' on the right. Each has a corresponding slide toggle. At the bottom, a 'Detailed endian swap' section contains a message: 'To be able to use the detailed swapping please select the "Detailed swap" option in the desired "Endian swap" select above.'

Figure 27. I/O configuration page

Status Byte



IMPORTANT

Adding a status byte to the I/O area after the data swap can cause data to be overwritten.

A status byte is used where a bit is:

- 1 if the corresponding network is online
- 0 if the corresponding network is not online

When status byte is enabled, it replaces the first data position in the data packet.

By default the status byte settings are disabled.

To enable **Modbus RTU status byte** and/or **PROFIBUS status byte**, click the slide toggle(s).

Clear Data

When clear data is enabled, any data sent to/from the Communicator while the network is offline is reset to zero.

By default the clear data settings are disabled.

To enable clear data, click the slide toggle for each network.

7.4. Configuration Notes

You can add notes to describe the Communicator configuration.

7.4.1. Add Configuration Note

Procedure

1. To open the **Configuration Notes** window, click on the **comments** icon .



Figure 28. Configuration note, comment icon

2. To add a new configuration note, click **Add**.





Figure 29. Add new configuration note

3. Write your configuration note and click **accept** ✓.



The screenshot shows a 'Configuration Notes' dialog box. At the top, there is a title bar with the text 'Configuration Notes' and a close button (X). Below the title bar, there is a blue button with a plus sign and the text '+ Add'. Underneath this, there is a date 'Aug 30, 2022'. Below the date, there is a text input field with the placeholder text 'Add note'. The input field contains the text 'Lorem ipsum dolor sit amet, consectetur adipiscing elit, sed do eiusmod tempor incididunt ut labore et dolore magna aliqua.' To the right of the input field, there are two small icons: a checkmark (✓) and a close button (X).

Figure 30. Write a configuration note

The configuration note is added to the list.

4. To close the window, click **close** ✕.
5. To save the configuration note, click **Apply** in the web-interface header, and follow the instructions.

7.4.2. View and Edit Configuration Notes

To view and/or edit a note, click on the **comments** icon .




Figure 31. Example: The comment icon indicates that there are three added notes

The configuration notes are listed in the **Configuration Note** window.




Figure 32. Example: The Configuration Notes window with added notes

7.5. Apply Configuration

Before You Begin

**NOTE**

When you apply the configuration, any existing configuration is overwritten.




Figure 33. Disconnect the Communicator from the networks

Before you can apply the configuration, ensure that there is no active communication on the Modbus RTU network or the PROFIBUS network where the Communicator is connected.


Procedure

To make the settings take effect, download the configuration to the Communicator:

1. In the web-interface header, click **Apply**



2. To confirm download, click **Apply**.
The configured settings are downloaded and applied to the system.



7.6. To Use an Existing Configuration

When you have configured a Communicator and want to use the same settings to configure additional Communicator, do the following.

Procedure




Figure 34. Files & firmware page

In the built-in web-interface of the Communicator with the configuration you want to use:

1. On the **Files & firmware** page, click **Export**
The configuration is saved in a configuration file and downloaded to your PC.

In the built-in web-interface of the new Communicator to be configured:

2. On the **Files & firmware** page, click **Import**
3. In the Import configuration window, click **Select file (.conf)**.
4. In the Open dialog box, browse to and select the configuration file and click **Open**.
5. To import the configuration file, click **Import**.

Result

All the configuration settings are imported.

To apply the settings, click **Apply** in the web-interface header, and follow the instructions.

8. PLC Configuration

8.1. PLC Device Security



IMPORTANT

It is important to maintain the cybersecurity of the Communicator.

Before connecting the Communicator to a PLC, ensure the PLC is configured and installed in accordance with the PLC supplier hardening guidelines.

8.2. Export Product GSD File

Option if the PLC program requires a product file, GSD (General Station Description) file, describing how the Communicator can be used on the high level network.

Procedure

You find the *PROFIBUS* GSD file on the Communicator built-in web interface **PROFIBUS** page.




Figure 35. Export Product GSD File

To export the GSD file:

Click **GSD file**.

The GSD file is downloaded to your PC.

8.3. Modbus Addressing and Register Mapping

For information about the Modbus Transactions, refer to the Modbus Organization.

8.3.1. The Difference Between Address and Register Start

To read or write data from a Modbus device you can use either Address or Register.



TIP
If Register is used, add +1 to the Address value.

Example 2. Modbus Function Code 0x04 Read Input Registers

Table 1. Modbus client values

Address	Register	Modicon Register
0	1	30001
1	2	30002
2	3	30003

Example 3. Modbus Function Code 0x03 Read Holding Registers

Table 2. Modbus client values

Address	Register	Modicon Register
0	1	40001
1	2	40002
2	3	40003

8.3.2. To Read and Write Data

To Read Data

To read data, you can use different Modbus Functions.

Discrete Inputs

- Modbus Function 0x02 Read Discrete Input Status

Discrete Input start at address 0.

Input Registers

- Modbus Function 0x04 Read Input Register
- Modbus Function 0x03 Read Holding Registers

The Input Registers starts at address 0 which corresponds to Register 1.

To use Read Holding Registers the address is offset to address 2048 which corresponds to Register 2049.

The first Input Register (30001)

The first Input Register (30001) can be read using Modbus Function code 0x04 Read Input Registers at Address 0 or Register 1.

You can also use Read Holding Registers (Modbus Function code 0x03) to read the same data (at Address 42048 = Register 42049) or use Read Discrete Inputs 0x02 at address 0..15.

To Write Data

To write data, you can use different Modbus Functions.

Coils

- Modbus Function 0x05 Force Single Coil
- Modbus Function 0x0F Force Multiple Coils

Coils starts at address 0.

Holding Registers

- Modbus Function 0x06 Write Single Register
- Modbus Function 0x10 Write Multiple Registers

The Holding Registers starts at address 0 which corresponds to Register 1.

Holding Register (40001)

The first Holding Register (40001) can be written to using Modbus Function code 0x06 Write Single Register at Address 0 or Register 1.

To read back what has been written, you can use Read Holding Registers 0x03 at address 0..749 = Register 1..750 (40001..40750) or Read Coils 0x01 at address 0..11999.

Data Encoding

Modbus uses the big-endian format for addresses and data items.

When a numerical value larger than one byte is transmitted, the most significant byte is sent first.

Example 4. Big-Endian Data Encoding

For a 16-bit register value of 0x1234:


- The first byte sent is 0x12.
- The second byte sent is 0x34.

See also [Convert Between Big-Endian and Little-Endian \(page 36\)](#).

8.3.3. Default Address Mode I/O Data Mapping


The following Modbus function codes are compatible with the default addressing mode.

Input Data to Client/Server - Data to Modbus



Process I/O data offset		Discrete input address		Input register address		Holding register address	
HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC
0x0000 - 0x0001	0 - 1	0x0000 - 0x000F	0 - 15	0x0000	0	0x0800	2048
0x0002 - 0x0003	2 - 3	0x0010 - 0x001F	16 - 31	0x0001	1	0x0801	2049
...	...	...	...	...	...	...	...
0x05D8 - 0x05D9	1496 - 1497	0x2EC0 - 0x2ECF	11968 - 11983	0x02EC	748	0x0AEC	2796
0x05DA - 0x05DB	1498 - 1499	0x2ED0 - 0x2EDF	11983 - 11999	0x02ED	749	0x0AED	2797

Output Data From Client/Server - Data From Modbus TCP




Process I/O data offset		Coil address		Holding register address	
HEX	DEC	HEX	DEC	HEX	DEC
0x0000 - 0x0001	0 - 1	0x0000 - 0x000F	0 - 15	0x0000	0
0x0002 - 0x0003	2 - 3	0x0010 - 0x001F	16 - 31	0x0001	1
...	...	...	...	...	...
0x05D8 - 0x05D9	1496 - 1497	0x2EC0 - 0x2ECF	11968 - 11983	0x02EC	748
0x05DA - 0x05DB	1498 - 1499	0x2ED0 - 0x2EDF	11983 - 11999	0x02ED	749

8.3.4. Legacy Address Mode I/O Data Mapping


The following Modbus function codes are compatible with the Modbus **Use legacy mode** setting.

Input Data to Client/Server - Data to Modbus



Process I/O data offset		Discrete input address		Coil address		Input register address		Holding register address	
HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC
0x0000 - 0x0001	0 - 1	0x0000 - 0x000F	0 - 15	0x0000 - 0x000F	0 - 15	0x0000	0	0x0000	0
0x0002 - 0x0003	2 - 3	0x0010 - 0x001F	16 - 31	0x0010 - 0x001F	16 - 31	0x0001	1	0x0001	1
...	...	...	...	...	...	...	...	...	...
0x01FC - 0x01FD	508 - 509	0x0FE0 - 0x0FEF	4064 - 4079	0x0FE0 - 0x0FEF	4064 - 4079	0x00FE	254	0x00FE	254
0x01FE - 0x01FF	510 - 511	0x0FF0 - 0x0FFF	4080 - 4095	0x0FF0 - 0x0FFF	4080 - 4095	0x00FF	255	0x00FF	255

Output Data From Client/Server - Data From Modbus



Process data offset		Discrete input address		Coil address		Input register address		Holding register address	
HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC
0x0000 - 0x0001	0 - 1	0x4000 - 0x400F	16384 - 16399	0x4000 - 0x400F	16384 - 16399	0x0400	1024	0x0400	1024
0x0002 - 0x0003	2 - 3	0x4010 - 0x401F	16400 - 16415	0x4010 - 0x401F	16400 - 16415	0x0401	1025	0x0401	1025
...	...	...	...	...	...	...	...	...	...
0x01FC - 0x01FD	508 - 509	0x4FE0 - 0x4FEF	20448 - 20463	0x4FE0 - 0x4FEF	20448 - 20463	0x04FE	1278	0x04FE	1278
0x01FE - 0x01FF	510 - 511	0x4FF0 - 0x4FFF	20464 - 20479	0x4FF0 - 0x4FFF	20464 - 20479	0x04FF	1279	0x04FF	1279

9. Verify Operation

Before You Begin

Ensure that the Communicator is connected to your PC, to a power supply and to the OT network.

See [Installation \(page 11\)](#).

9.1. Communicator Status Monitor

On the Home page, you can get a quick overview of the network and the Communicator operating status.




Figure 36. Home page

Gateway status

Overview the Communicator LED indications remotely.

For information about the LED indication, see [Communicator LED Indicators \(page 52\)](#).

Network Status and Settings

Overview communication status and the current networks settings.

Status Symbols

Symbol	Description
	Internal error has occurred, and operation cannot be guaranteed.
	Out of Specification.
	Check Function: • Initial state where non network components are started and configured. • Network startup in progress. • Invalid configuration detected.
	Normal operation.

9.2. Communicator LED Indicators



NOTE
Before you can verify operation, you must configure the Communicator.




Figure 37. Gateway status (A), Lower connector (B), Upper connector (C) and Security Switch (D)

LED A - Gateway status	
Operation Status	Description
Off	No power
Green, flashing	Startup phase
Green, solid	Operational
Red, flashing	Invalid configuration
Green/Red, flashing	Power up self-test/Firmware update/Firmware recovery

LED B - PROFIBUS, Lower connectors	
Operation status.	PROFIBUS
Off	No power/No data exchange.
Green, solid	Operate, data exchange.
Green, flashing	Clear, data exchange.
Red, one flash	Parameterization error.
Red, two flash	PROFIBUS configuration error.

LED C - Modbus RTU, Upper connector	
Operation status.	Modbus RTU
Off	No power, no active nodes, or all nodes are stopped.
Green, flashing	Waiting for first Modbus message.
Green, solid	At least one Modbus message received.
Red, solid	Fatal event.

LED C - Modbus RTU, Upper connector	
Operation status.	Modbus RTU
Red, flashing	Connection timeout. No Modbus messages has been received within the configured process active timeout time.

Security switch - LED D	
Operation status	Description
Off	No power/Security switch is unlocked/Exception/Fatal error
Green	Security switch is locked

Fatal Error and Exception Error

Fatal error: A fatal error causes the Communicator firmware application to crash in an uncontrolled manner.

Exception error: An exception error causes the Communicator to enter a controlled error state. The Communicator firmware application is still running.

LED	Fatal error	Exception error
A	Red, solid	Red, solid
B	Red, solid	Off
C	Red, solid	Off
D	Off	Off

9.3. Ethernet LED Indicators




Figure 38. LED A. Activity LED B. Not used

LED A	Function
Off	No link (or no power)
Green	Link (100 Mbit/s) established
Green, flashing	Activity (100 Mbit/s)
Yellow	Link (10 Mbit/s) established
Yellow, flashing	Activity (10 Mbit/s)

LED B	Function
Off	Not used

10. Maintenance

10.1. Action on Fatal Error




Figure 39. System page, Action on fatal error menu

A fatal error causes the Communicator firmware application to crash in an uncontrolled manner.

You can configure how the Communicator should behave if a fatal error occurs.

In the **Action on fatal error** menu, select one of the following settings:

- **Locks up and indicates fatal error:** Default setting, the Communicator locks up and the LED indicators indicate a fatal error.
- **Resets and starts up again:** The Communicator is rebooted to reset the system and return to normal operation.

10.2. Configuration Port IP Settings

On the **System** page you can change the IP address of the Communicator configuration port.




Figure 40. System page, Configuration port settings

Default Configuration Port IP settings

Setting	Default value
IP address	192.168.0.10
Subnet mask	255.255.255.0
Gateway	There is no default Gateway address.

10.3. Configuration File Handling

10.3.1. Export Configuration

You can export the current configuration, to import and use the same settings to configure additional Communicator.




Figure 41. Files & firmware page

To export a configuration file:

In **Files & firmware**, click **Export**.

The configuration settings are stored in a .conf file and downloaded to your PC.

10.3.2. Import Configuration

To easily configure multiple Communicator with the same settings, you can import a configuration file.

Before You Begin

The supported file format is .conf.

Procedure




Figure 42. Files & firmware page

Import configuration file:

1. On the **Files & firmware** page, click **Import**.
2. In the Import configuration window, click **Select file (.conf)**.
3. In the Open dialog box, browse to and select the configuration file and click **Open**.
4. In the Import configuration window, click **Import**.
5. In the Communicator address settings window:
 - To import IP settings from the selected configuration file, click **Imported settings**.
All configuration settings are imported.
 - To continue using the current IP settings, click **Configured settings**.
All configuration settings except the IP settings are imported.
6. The configuration file is parsed.
 - If the configuration is compatible, the settings are imported.
 - If any compatibility mismatches occur, a message about the mismatch appears.
7. To apply the settings, click **Apply** in the web-interface header, and follow the instructions.

10.4. Clear and Revert Configuration

You can restore all settings in a configuration to the default settings.

Procedure




Figure 43. Files & firmware page

To Clear the Configuration

When you want to clear a configuration and return to the default settings.

1. On the **Files & firmware** page, click **Clear**.
2. In the Confirm clear window, click **Clear**.
3. To apply the change, click **Apply** in the web-interface header, and follow the instructions.

To Revert the Configuration

When you want to remove any configuration made in a current session and re-load the configuration from the gateway.

1. On the Files & firmware page, click **Revert**.
2. In the Confirm revert window, click **Revert**.
3. To apply the change, click **Apply** in the web-interface header, and follow the instructions.

10.5. Firmware Management

10.5.1. View the Firmware Version

On the **Support** page, you can view the current applied firmware version.




Figure 44. Support page, Product information example

10.5.2. Firmware and Configuration Compatibility

Compatibility after firmware upgrade

Current configuration is still compatible after upgrading the firmware.

Compatibility after firmware downgrade

**IMPORTANT**
Compatibility after a firmware downgrade cannot be guaranteed.

The current configuration may use features not available in the older firmware version.

10.5.3. Firmware File Validation

Before the firmware file is imported into the system, the firmware upgrade function performs a validation of the file, to ensure that:

- the firmware is compatible with the Communicator hardware
- the firmware is suited for the product
- the officially HMS software signatures are valid
- that the firmware file is not corrupt or damaged

If the firmware file does not pass the validation, the firmware file is rejected and an error message appear.

10.5.4. Update Firmware

Before You Begin

Ensure to disconnect the Communicator from the OT networks.

Procedure




Figure 45. Files & firmware page

To update the firmware:

1. On the **Files & firmware** page, click **Upload**.
2. In the Upload Firmware window, click **Select firmware (.hiff)**.
3. In the Open dialog box, browse to and select the firmware file and click **Open**.
4. To start the firmware upgrade, click **Update firmware**.
The firmware file is validated and transferred.

Result

- If the firmware file passes the validation: The firmware is upgraded and then the Communicator automatically reboots, for the upgrade to take effect.
- If the firmware file is rejected: An error message appears.

10.6. Change Language

Default language is **English**.

To change the language of the Communicator built-in web interface:

1. In the Communicator built-in web-interface header, click the **Language** icon .




Figure 46. Language menu

2. Select a new language from the list.




Figure 47. Example: Change language to German

The language change takes effect immediately.

11. Troubleshooting

11.1. Diagnostics

11.1.1. I/O Data

On the **Diagnostics**, **I/O data** page you can monitor how the data flow between the **Modbus RTU** side and the **PROFIBUS** side, including any configured endian conversions.

Anybus Communicator
Article Number: ABCXXXXX Version: 1.02.03 Serial Number: ABC123456 GUI Version: 1.22.01

I/O data

Start Modbus RTU (X2) ☒ PROFIBUS (X3) ☒ Hex Dec Ascii

Data from PROFIBUS (X3) to the Anybus Communicator

Address	Data
0 ... 7	00 01 02 03 04 05 06 07
8 ... 15	08 09 0a 0b 0c 0d 0e 0f
16 ... 23	10 11 12 13 14 15 16 17
24 ... 31	18 19 1a 1b 1c 1d 1e 1f
32 ... 39	20 21 22 23 24 25 26 27
40 ... 47	28 29 2a 2b 2c 2d 2e 2f
48 ... 55	30 31 32 33 34 35 36 37
56 ... 63	38 39 3a 3b 3c 3d 3e 3f

Time (d:hh:mm:ss.ms): 0:03:17:46.911

Data from the Anybus Communicator to PROFIBUS (X3)

Address	Data
0 ... 7	00 01 02 03 04 05 06 07
8 ... 15	08 09 0a 0b 0c 0d 0e 0f
16 ... 23	10 11 12 13 14 15 16 17
24 ... 31	18 19 1a 1b 1c 1d 1e 1f
32 ... 39	20 21 22 23 24 25 26 27
40 ... 47	28 29 2a 2b 2c 2d 2e 2f
48 ... 55	30 31 32 33 34 35 36 37
56 ... 63	38 39 3a 3b 3c 3d 3e 3f

Time (d:hh:mm:ss.ms): 0:03:17:46.974

Figure 48. I/O data

I/O data is updated twice every second.

Switch between the OT networks

To switch between the networks, select **Modbus RTU** or **PROFIBUS**.

Select how data is displayed

To choose if the data should be displayed in Hexadecimal, Decimal or ASCII, click **Hex**, **Dec** or **Ascii**.

Start and Stop Data flow

- To start the data flow, click **Start**.
- To end the data flow, click **Stop**.

11.1.2. Event Log




Figure 49. Event log page example

How To Analyze the Information

The log follows the FIFO principle, first in and first out. The oldest (first) value is processed first.

Time (d:hh:mm:ss.ms)	The duration from when the X-gateway was powered on until the event occurred.
Message	A brief description of the event.
Severity	The severity of the event occurred. For description of the symbols, see Communicator Status Monitor (page 50) .
Source	Communicator
	PROFIBUS
	Modbus RTU
Sub-source	The nodes connected to the subnetwork and the PLC connected to the high level network. If there is a problem with a node the node name is displayed in the Sub-source column.
	Example 5. Sub-source number
	If the node name is 5, number 5 is displayed in the Sub-source column.

To clear the current log, click **Clear**.

11.1.3. LED Status

On the Home page, you can remotely monitor the Communicator LED status.




Figure 50. Home page

For information about the LED indication, see [Communicator LED Indicators \(page 52\)](#).

11.2. Reset to Factory Settings

Before You Begin

Factory reset will reset any on site made configuration changes and set the Communicator to the same state as leaving HMS production.

When the Firmware has been updated, factory reset will revert the Communicator configuration to initial state after the update.

Procedure

To reset the Communicator:

1. Disconnect the Communicator from power.




Figure 51. Disconnect power

2. Use a pointed object, such as a ballpoint pen to press and hold the **Reset** button.




Figure 52. Press and hold **Reset** button

3. While holding the **reset** button, reconnect the Communicator to power.




Figure 53. Hold **Reset** button and reconnect power

4. Release the **reset** button.
The Communicator enters exception state.
5. Reboot the Communicator.

Result

When the Communicator has successfully rebooted, the Communicator configuration is reset to the factory default configuration or the current configuration after firmware upgrade.

To Do Next

To ensure that the Communicator built-in web-interface is synchronized.

1. Open the Communicator built-in web interface.

2. Navigate to the **Files & firmware** page and click **Revert**.




Figure 54. Files & firmware, Revert

11.3. Firmware Upgrade Error Management

Before You Begin

If the firmware update process is interrupted or if the power is lost during the update process, the Communicator goes into fallback mode.

The firmware file from the latest update attempt remains in the flash memory, but it is not active.

Procedure

To complete the interrupted firmware update:

1. Disconnect the Communicator from power.




Figure 55. Disconnect power

2. Reconnect the Communicator to power.




Figure 56. Reconnect power

3. Leave the Communicator for 10 minutes.
The Gateway status led indicator flashes red and green until the firmware upgrade is completed.




Figure 57. Firmware upgrade LED indication

Result

The Communicator recover and return to normal operation.




Figure 58. Recover and return to normal operation

To Do Next

To check LED status, refer to [Communicator LED Indicators \(page 52\)](#)

11.4. Support

11.4.1. Support Package




Figure 59. Support page example

Before you create a ticket for technical support, generate a support package.

The support package contains information about what has occurred and will help the Anybus technical support team resolve the support case as quickly and efficiently as possible.

Support Package Content

The information in the support package is available to open and read, the files are not locked or encrypted.

Generate Support Package

On the **Support** page, click **Generate**.

A zip file with the support files is downloaded to your PC.

Create a Support Ticket

1. On the **HMS Networks** home page, navigate to the **Support** main menu and click **Support portal**.
2. In the **Support portal**, create a support ticket and upload the support package.

12. Technical Data

For complete technical specifications and regulatory compliance information, please visit www.hms-networks.com.

12.1. Technical Specifications

Article identification	ABC4028
Configuration connector	RJ45
Upper connector	7-pin screw connector
Lower connector	9-pin D-sub
Power connector	3-pin screw connector
Power supply	12-30 VDC, Reverse voltage protection and short circuit protection
Power consumption	Typical: 90 mA @ 24 V (2.2 W) Max: 3 W
Storage temperature	-40 to +85 °C
Operating temperature	-25 to +70 °C
Humidity	EN 60068-2-78: Damp heat, +40°C, 93% humidity for 4 days EN 60068-2-30: Damp heat, +25°C – +55°C, 95% RH, 2 cycles
Vibration	See datasheet
Housing material	Plastic, See datasheet for details
Protection class	IP20
Product weight	150 g
Dimensions	27 x 144 x 98 mm (W x H x D) with connectors included
Mounting	DIN-rail

13. End Product Life Cycle

13.1. Secure Data Disposal

**IMPORTANT**

To avoid exposure of sensitive data, always perform a factory reset before decommissioning the equipment.

Factory reset will reset any on site made configuration changes and set the Communicator to the same state as leaving HMS production.

See [Reset to Factory Settings \(page 65\)](#).

14. Reference Guides

14.1. About Input Registers and Holding Registers

Modbus data is most often read and written as registers which are 16-bit pieces of data.

Holding registers and Input registers are both 16-bit registers.

**TIP**

If Register is used, add +1 to the Address value.

Input Registers

Input registers can only be read.

Holding Registers

Holding registers can be read or written.

These registers can be used for a variety of things such as inputs, outputs, configuration data, or other requirement for holding data.

14.2. Modbus Data Model

Discretes Input	Single bit	Read-Only	Data can be provided by the I/O system.
Coils	Single bit	Read-Write	Data can be alterable by the application program.
Input Registers	16-bit word	Read-Only	Data can be provided by the I/O system
Holding Registers	16-bit word	Read-Write	Data can be alterable by the application program.

Reference: MODBUS Application Protocol Specification V1.1b3, April 26 2012

For more information refer to the Modbus organization website.

14.3. Modbus Function Codes

Reference: MODBUS Application Protocol Specification V1.1b3, April 26 2012

For more information refer to the Modbus organization website.

Nr	Function	Function Code	Description
1	Read Coils	0x01	Read from 1 to 2000 contiguous status of coils in a remote device.
2	Read Discrete Inputs	0x02	Read from 1 to 2000 contiguous status of discrete inputs in a remote device.
3	Read Holding Registers	0x03	Read the contents of a contiguous block of holding registers in a remote device.
4	Read Input Registers	0x04	Read from 1 to 125 contiguous input registers in a remote device.
5	Write Single Coil	0x05	Write a single output to ON or OFF in a remote device.
6	Write Single Register	0x06	Write a single holding register in a remote device.
8	Diagnostics (Serial Line only)	0x08	For Modbus RTU, not supported by Modbus TCP. Diagnostics provides a series of tests to check the communication system between a client device and a server, or to diagnose various internal error conditions within a server.
15	Write Multiple Coils	0x0F	In a sequence of coils, force each coil to either ON or OFF in a remote device.
16	Write Multiple Registers	0x10	Write a block of contiguous registers in a remote device.
22	Mask Write Register	0x16	In a single transaction, modify the contents of a specified holding register using a combination of an AND mask, an OR mask, and the register's current contents. Can be used to set or clear individual bits in the register.
23	Read/Write Multiple Registers	0x17	Performs a combination of one read operation and one write operation. The write operation is performed before the read.

14.4. Modbus Exception Codes

Exception Code	Name	Description
01	Illegal Function	The server does not recognize or permit the function code.
02	Illegal Data Address	The data address (register, discrete input or coil number) is not an permitted address for the server. If multiple registers were requested, at least one was not permitted.
03	Illegal Data Value	A value in the query data field is not allowed by the server. This indicates there is a problem with the structure of the rest of the request, such as an incorrect implied length.

Reference: MODBUS Application Protocol Specification V1.1b3, April 26 2012

For more information refer to the Modbus organization website.