

Anybus[®] Communicator[™] - Modbus RTU Server to Common Ethernet

STARTUP GUIDE

SP3392

Version 1.0

Publication date 2025-04-07



Important User Information

Disclaimer

The information in this document is for informational purposes only. Please inform HMS Networks of any inaccuracies or omissions found in this document. HMS Networks disclaims any responsibility or liability for any errors that may appear in this document.

HMS Networks reserves the right to modify its products in line with its policy of continuous product development. The information in this document shall therefore not be construed as a commitment on the part of HMS Networks and is subject to change without notice. HMS Networks makes no commitment to update or keep current the information in this document.

The data, examples and illustrations found in this document are included for illustrative purposes and are only intended to help improve understanding of the functionality and handling of the product. In view of the wide range of possible applications of the product, and because of the many variables and requirements associated with any particular implementation, HMS Networks cannot assume responsibility or liability for actual use based on the data, examples or illustrations included in this document nor for any damages incurred during installation of the product. Those responsible for the use of the product must acquire sufficient knowledge in order to ensure that the product is used correctly in their specific application and that the application meets all performance and safety requirements including any applicable laws, regulations, codes and standards. Further, HMS Networks will under no circumstances assume liability or responsibility for any problems that may arise as a result from the use of undocumented features or functional side effects found outside the documented scope of the product. The effects caused by any direct or indirect use of such aspects of the product are undefined and may include e.g. compatibility issues and stability issues.

Copyright © 2025 HMS Networks

Contact Information

Postal address:

Box 4126

300 04 Halmstad, Sweden

E-Mail: info@hms.se

1. Preface

1.1. About This Document

This document describes how to install Anybus® Communicator™.

For additional documentation and software downloads, FAQs, troubleshooting guides and technical support, please visit www.hms-networks.com/technical-support.

1.2. Document Conventions

Safety Symbols

**DANGER**

Instructions that must be followed to avoid an imminently hazardous situation which, if not avoided, will result in death or serious injury.

**WARNING**

Instructions that must be followed to avoid a potential hazardous situation that, if not avoided, could result in death or serious injury.

**CAUTION**

Instruction that must be followed to avoid a potential hazardous situation that, if not avoided, could result in minor or moderate injury.

**IMPORTANT**

Instruction that must be followed to avoid a risk of reduced functionality and/or damage to the equipment, or to avoid a network security risk.

Information Symbols



NOTE

Additional information which may facilitate installation and/or operation.



TIP

Helpful advice and suggestions.

1.3. Trademarks

Anybus® is a registered trademark of HMS Networks.

All other trademarks are the property of their respective holders.

1.4. About the EtherCAT Terminology

The EtherCAT® Technology Group has changed the terminology for Master and Slave.

Master is called **MainDevice**

Abbreviated: **MDevice**

Slave is called **SubordinateDevice**

Abbreviated: **SubDevice**

2. Safety

2.1. Intended Use

The intended use of this equipment is as a communication interface and gateway.

The equipment receives and transmits data on various physical layers and connection types.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

2.2. General Safety

**CAUTION**

Ensure that the power supply is turned off before connecting it to the equipment.

**CAUTION**

This equipment contains parts that can be damaged by electrostatic discharge (ESD). Use ESD prevention measures to avoid damage.

**CAUTION**

To avoid system damage, the equipment should be connected to ground.

**IMPORTANT**

Using the wrong type of power supply can damage the equipment. Ensure that the power supply is connected properly and of the recommended type.

3. Cybersecurity

3.1. General Cybersecurity



IMPORTANT

It is important to maintain the cybersecurity of the Communicator.

Before connecting the Communicator to a PLC, ensure the PLC is configured and installed in accordance with the PLC supplier hardening guidelines.



IMPORTANT

To physically secure networks and equipment and to prevent unauthorized access, it is recommended to install the equipment in a locked environment.



IMPORTANT

After completing the configuration of the Communicator, lock the security switch to prevent unauthorized access to the Communicator built-in web interface.



IMPORTANT

To avoid exposure of sensitive data, always perform a factory reset before decommissioning the equipment.

Factory reset will reset any on site made configuration changes and set the Communicator to the same state as leaving HMS production.

4. Preparation

4.1. Support and Resources

For additional documentation and software downloads, FAQs, troubleshooting guides and technical support, please visit www.hms-networks.com/technical-support.

**TIP**

Have the product article number available, to search for the product specific support web page. You find the product article number on the product cover.

4.2. Cabling

Have the following cables available:

- Power cable.
- Ethernet cable for configuration.
- Ethernet cable x 1 for connecting to the network.
- 7-pin screw terminal block connector is included with the product.

4.3. Mechanical Tools and Equipment

Have the following tools available:

- Flat-head screwdriver, size 5.5 mm
Needed when removing the Communicator from DIN-rail.
- Flat-head screwdriver, size 3 mm
Needed when connecting the cables to the 7-pin connector.

4.4. HMS Software Applications

Download the software installation files and user documentation from
www.hms-networks.com/technical-support.

HMS IPconfig

Use the software application HMS IPconfig and scan your network to discover and change the Communicator IP address and to access the Communicator built-in web interface.



NOTE

As an alternative, you can set a static IP address within the same IP address range as the Communicator IP address on the computer accessing the Communicator built-in web interface.



NOTE

HMS IPconfig is only available for Windows.

4.5. Software License Information

For license agreements regarding the third-party software used in the Communicator, refer to the *LICENSE.txt* file(s) included in the Communicator firmware update package zip file.

To download the Communicator firmware update package zip file, please visit
www.hms-networks.com/technical-support.



TIP

Have the product article number available, to search for the product specific support web page. You find the product article number on the product cover.

5. Installation

5.1. Anybus Communicator Variants

Order Code	Network 1, Upper Connector	Network 2, Lower Connector
ABC4024	Modbus RTU Server	EtherNet/IP
ABC4025	Modbus RTU Server	Modbus TCP
ABC4026	Modbus RTU Server	EtherCAT
ABC4027	Modbus RTU Server	PROFINET

See also [Connector Port Guide \(page 10\)](#).

5.2. Label the Communicator with Network Stickers

If you update the pre-configured firmware, you can use the included stickers to relabel the laser engraved marking next to the network LED indicators and connectors. See also [Configure the Communicator \(page 23\)](#).

- Check which LEDs indicate the networks of the firmware installed on the Communicator. For information about the LED indication, see [Communicator LED Indicators \(page 27\)](#).
- Check which connector is used for which network of the firmware installed on the Communicator. See [Connector Port Guide \(page 10\)](#).




Figure 1. Stickers placed next to the Communicator LED indicators and connectors

5.3. DIN Rail Mounting

**IMPORTANT**

The equipment must be electrically grounded through the DIN rail for EMC compliance. Make sure that the equipment is correctly mounted on the rail and that the rail is properly grounded.

**IMPORTANT**

To physically secure networks and equipment and to prevent unauthorized access, it is recommended to install the equipment in a locked environment.




Figure 2. Attach the Communicator on the DIN rail

5.4. Connector Port Guide

This topic applies to different product variants for different networks.




Figure 3. Communicator connector ports

Position	Port Number	Connector	Port Usage
A	X1	Ethernet RJ45	Configuration port
B	X2	7 Pin Screw Terminal Block	Network X2: Modbus RTU network
C	X3.1	Ethernet RJ45	Network X3: EtherNet/IP, Modbus TCP, PROFINET, or EtherCAT
D	X3.2	Ethernet RJ45	Network X3: EtherNet/IP, Modbus TCP, PROFINET, or EtherCAT

5.5. Connect to Networks

5.5.1. Procedure




Figure 4. Connect Network X2: Modbus RTU (3) and Network X3: EtherNet/IP, Modbus TCP, PROFINET, or EtherCAT (4)

Procedure


1. Insert the cable wires into the 7-pin connector and tighten the wire clamp screws (1). See [Modbus RTU Serial Connector Pinout](#) (page 12).
2. Connect the 7-pin connector to the Communicator (2).
3. Connect the Communicator to the Network X2: Modbus RTU network (3).
4. Connect the Communicator to the Network X3: EtherNet/IP, Modbus TCP, PROFINET, or EtherCAT (4).

5.5.2. Modbus RTU Serial Connector Pinout




NOTE

Use minimum 90 oC copper (Cu) wire only.

7-pin connector	Pin	Signal
	1	+5 V OUT
	2	RS485+ A
	3	RS485- B
	4	Signal GND
	5	Functional Earth (FE)
	6	RS232 Tx Transmit Data
	7	RS232 Rx Receive Data

5.5.3. Ethernet RJ45 Connector Pinout

Ethernet RJ45 Connector	Pin	Description
	1	TD+
	2	TD-
	3	RD+
	4	Not used
	5	Not used
	6	RD-
	7	Not used
	8	Not used

5.6. Connect to Power



CAUTION

Ensure that the power supply is turned off before connecting it to the equipment.



IMPORTANT

Using the wrong type of power supply can damage the equipment. Ensure that the power supply is connected properly and of the recommended type.





Figure 5. Connect to power

Power Connector Pinout

Power port	Pin	Description
	1	12-30 VDC Power Connector
	2	Ground (GND)
	3	Functional Earth (FE)

5.7. Security Switch



IMPORTANT

After completing the configuration of the Communicator, lock the security switch to prevent unauthorized access to the Communicator built-in web interface.

When the security switch is in its locked position, the Communicator built-in web interface cannot be accessed, and the Communicator cannot be configured using the built-in web interface. Network specific parameters, configured via the PLC is still available.

To Lock and Unlock the Security Switch




Figure 6. Security switch in locked and unlocked position

Use a pointed object, such as a ballpoint pen.

- To **lock** the security switch, push the toggle towards the **Communicator front**.
- To **unlock** the security switch, push the toggle towards the **Communicator back**.

Security Switch Status LED




Figure 7. Security switch locked status LED

When the security switch is in its:

- locked position, the security switch status LED turn solid green.
- unlocked position, the security switch status LED is turned off.

5.8. Lock the Cables




Figure 8. Lock the cables

To strain relieve the cables, place a cable tie in the holder and lock the cables.

5.9. DIN Rail Demount

Before You Begin



IMPORTANT

Be careful when removing the Communicator from the DIN-rail. If not removed properly, the DIN rail locking mechanism and the product cover can break.

Have a flat-blade screwdriver, size 5.5 mm, available.

Procedure

Remove the Communicator from the DIN rail:

1. Insert the screwdriver into the Communicator DIN rail locking mechanism.
2. To unlock the Communicator DIN rail locking mechanism, turn the screwdriver clockwise.




Figure 9. Unlock the Communicator

3. Hold the screwdriver in the DIN rail locking mechanism while you unhook the Communicator from the DIN rail.




Figure 10. Unhook the Communicator

6. Configuration

6.1. Connect to PC and Power




Figure 11. Connect to PC and Power

6.2. Find the Communicator on Your PC

The Communicator default IP address is 192.168.0.10.

To be able to access the Communicator built-in web interface you may need to adjust the IP settings, choose one of the following methods:

Option 1 | Set a static IP address on the PC



On the PC accessing the Communicator built-in web interface, set a static IP address within the same IP address range as the Communicator IP address.

To access the Communicator built-in web interface, ensure that port 80 TCP is open in your PC Windows Firewall.

Note that when you change to a static IP address on your PC, internet access is lost.

Option 2 | Change the IP address on the Communicator configuration port



Use the software application HMS IPconfig to find and change the IP address on the Communicator configuration port, to one within the same IP address range as the PC accessing the Communicator built-in web interface.

To download the installation files, please visit www.hms-networks.com/technical-support and enter the product article number to search for the Communicator support web page. You find the product article number on the product cover.

6.3. Configure the Communicator





Figure 12. Communicator built-in web interface

By default, the Common Ethernet Communicator is preconfigured with the Modbus RTU to PROFINET networks.

Download files and access the Communicator built-in web interface

1. Download firmware files and documentation.
To download firmware files and user documentation for the desired Communicator network version, visit www.hms-networks.com/technical-support and navigate to the **Common Ethernet Communicator ABC4092** product page.
2. Open the Communicator built-in web interface.
You can open the built-in web interface in HMS IPconfig or by entering the Communicator IP address in your web browser.
3. Optional step: The default web interface language is **English**.
To change language, click the **Language** icon  and select a new language from the list. The language change takes effect immediately.

Change the preconfigured networks

1. In the **Files & firmware** page **Firmware management** section, click **Upload**.
2. In the Upload Firmware window, click **Select firmware (.hiff)**.
3. In the Open dialog box, browse to and select the firmware file and click **Open**.
4. To start the firmware upgrade, click **Update firmware**.
 - The firmware file is validated and transferred.
 - The Communicator reboots and is reset to the factory default settings for the Communicator network variant you have updated to.


Configure the Communicator

1. Open the Communicator built-in web interface.
You can open the built-in web interface in HMS IPconfig or by entering the Communicator IP address in your web browser.
2. The built-in web interface takes you through the steps to configure the Communicator.
For in-depth information about the configuration, refer to the user manual for the installed Communicator network variant.

6.4. Change Language

Default language is **English**.

To change the language of the Communicator built-in web interface:

1. In the Communicator built-in web-interface header, click the **Language** icon .




Figure 13. Language menu

2. Select a new language from the list.




Figure 14. Example: Change language to German

The language change takes effect immediately.

7. Technical Data

For complete technical specifications and regulatory compliance information, please visit www.hms-networks.com.

7.1. Technical Specifications

Article identification	ABC4092
Configuration connector	RJ45
Upper connector	7-pin screw connector
Lower connector	RJ45 x 2
Power connector	3-pin screw connector
Power supply	12-30 VDC, Reverse voltage protection and short circuit protection
Power consumption	Typical: 90 mA @ 24 V (2.2 W) Max: 3 W
Storage temperature	-40 to +85 °C
Operating temperature	-25 to +70 °C
Humidity	EN 60068-2-78: Damp heat, +40°C, 93% humidity for 4 days EN 60068-2-30: Damp heat, +25°C – +55°C, 95% RH, 2 cycles
Vibration	See datasheet
Housing material	Plastic, See datasheet for details
Protection class	IP20
Product weight	150 g
Dimensions	27 x 144 x 98 mm (W x H x D) with connectors included
Mounting	DIN-rail

8. Communicator LED Indicators



NOTE

Before you can verify operation, you must configure the Communicator.




Figure 15. Gateway status (A), Lower connector (B), Upper connector (C) and Security Switch (D)

LED A - Gateway status	
Operation Status	Description
Off	No power
Green, flashing	Startup phase
Green, solid	Operational
Red, flashing	Invalid configuration
Green/Red, flashing	Power up self-test/Firmware update/Firmware recovery

LED B - EtherNet/IP, PROFINET, EtherCAT, or Modbus TCP - Lower connectors					
LED C - Modbus RTU, Upper connector					
Operation status.	Modbus RTU	EtherNet/IP	PROFINET	EtherCAT	Modbus TCP
Off	No power, no active nodes, or all nodes are stopped.	No power/No EtherNet/IP IP address.	No power/No connection with IO controller.	No power/ EtherCAT device in 'INIT'-state	No power/No Modbus TCP IP address
Green, flashing	Waiting for first Modbus message.	EtherNet/IP online, no connections established.	Used by engineering tools to identify the node on the network	EtherCAT device in 'PREOPERATION AL'- state	Modbus TCP online, no messages received.
Green, one flash	N/A	N/A	Connection with IO controller established. IO controller in STOP state or IO data bad.	EtherCAT device in 'SAFEOPERATION AL'- state	N/A
Green, solid	At least one Modbus message received.	EtherNet/IP online, one or more connections established.	PROFINET online, one or more connections established.	EtherCAT device in 'OPERATIONAL'- stat	Modbus TCP online, at least one message received.
Red, solid	Fatal event.	Duplicated EtherNet/IP IP address.	Fatal event.	Fatal event.	IP address conflict detected.
Red, one flash	N/A	N/A	Station name not set.	Unsolicited state change. SubDevice application has changed the EtherCAT state autonomously	N/A
Red, two flash	N/A	N/A	IP address not set.	Sync Manager watchdog timeout.	N/A
Red, three flash	N/A	N/A	Expected Identification differs from Real Identification.	N/A	N/A
Red, flashing	Connection timeout. No Modbus	One or more connections timed out.	One or more connections timed out.	Invalid configuration.	Connection timeout.

LED B - EtherNet/IP, PROFINET, EtherCAT, or Modbus TCP - Lower connectors					
LED C - Modbus RTU, Upper connector					
Operation status.	Modbus RTU	EtherNet/IP	PROFINET	EtherCAT	Modbus TCP
	messages has been received within the configured process active timeout time.				
Green/Red, flashing	N/A	N/A	N/A	EtherCAT RUN (green) and ERROR (red) LED combined*	N/A

Security switch - LED D	
Operation status	Description
Off	No power/Security switch is unlocked/Exception/Fatal error
Green	Security switch is locked

Fatal Error and Exception Error

Fatal error: A fatal error causes the Communicator firmware application to crash in an uncontrolled manner.

Exception error: An exception error causes the Communicator to enter a controlled error state. The Communicator firmware application is still running.

LED	Fatal error	Exception error
A	Red, solid	Red, solid
B	Red, solid	Off
C	Red, solid	Off
D	Off	Off

9. Ethernet LED Indicators




Figure 16. LED A. Activity LED B. Not used

LED A	Function
Off	No link (or no power)
Green	Link (100 Mbit/s) established EtherCAT: Link established
Green, flashing	Activity (100 Mbit/s) EtherCAT: Activity
Yellow	Link (10 Mbit/s) established EtherCAT: Yellow LED is not used
Yellow, flashing	Activity (10 Mbit/s) EtherCAT: Yellow LED is not used

LED B	Function
Off	Not used

This page is intentionally left blank.

This page is intentionally left blank.